

Installer manual

NIBE™ F1245

Ground source heat pump

IHB GB 0926-2
031337

Quick guide

Navigation



A detailed explanation of the button functions can be found on page 39.

How to scroll through menus and make different settings is described on page 41.

Set the indoor climate



The mode for setting the indoor temperature is reached, when in the start mode in the main menu, by pressing the OK button twice. Read more about the settings on page 43.

Increase hot water volume



To temporarily increase the amount of hot water , first turn the control knob to mark menu 2 and then press the OK button twice. Read more about the settings on page 51.

In event of disturbances in comfort

If a disturbance in comfort of any type occurs there are some measures that can be taken before you need to contact your installer. See page 69 for instructions.

Table of Contents

1 Important information 2
Safety information 2

2 Delivery and handling 5
Transport 5
Assembly 5
Supplied components 6
Removing the covers 7
Removing parts of the insulation 7

3 The heat pump design 9
Electrical cabinets 10
Cooling section 12

4 Pipe connections 13
General 13
Dimensions and pipe connections 14
Brine side 14
Hot water heater 15
Heating medium side 15
Docking alternatives 16

5 Electrical connections 18
General 18
Connections 20
Settings 22
Optional connections 23
Connecting accessories 25

6 Commissioning and adjusting 26
Preparations 26
Filling and venting 26
Start guide 27
Post adjustment and venting 36

7 Control - Introduction 39
Display unit 39
Menu system 40

8 Control - Menus 43
Menu 1 - INDOOR CLIMATE 43
Menu 2 - HOT WATER 51
Menu 3 - INFO 53
Menu 4 - HEAT PUMP 54
Menu 5 - SERVICE 58

9 Service 63
Service actions 63

10 Disturbances in comfort 69
Info-menu 69
Manage alarm 69
Troubleshooting 69

11 Accessories 71

12 Technical data 72
Dimensions and setting-out coordinates 72
Technical specifications 73

Item register 77

1 Important information

Safety information

This manual describes installation and service procedures for implementation by specialists.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
Children should be supervised to ensure that they do not play with the appliance.
Rights to make any design or technical modifications are reserved.
©NIBE 2008.

Symbols

NOTE
This symbol indicates danger to machine or person.

Caution
This symbol indicates important information about what you should observe when maintaining your installation.

TIP
This symbol indicates tips on how to facilitate using the product.

Serial number

The serial number can be found at the bottom right of the front cover and in the info menu (menu 3.1).



Caution
Always give the product's serial number when reporting a fault.

Country specific information

Installer manual

This installer manual must be left with the customer.

Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person.

Cut out this page after installation and give it to the owner of the heat pump. Fill in the page for information about installation data in the User manual.

✔	Description	Notes	Signature	Date
Brine (page 14)				
	System flushed			
	System vented			
	Antifreeze			
	Level/Expansion vessel			
	Particle filter			
	Safety valve			
	Shut-off valves			
	Circulation pump setting			
Heating medium (page 15)				
	System flushed			
	System vented			
	Expansion vessel			
	Particle filter			
	Safety valve			
	Shut-off valves			
	Circulation pump setting			
Electricity (page 18)				
	Fuses heat pump			
	Fuses property			
	Outdoor sensor/Indoor sensor			
	Current sensor			
	Safety breaker			
	Earth circuit-breaker			
	Setting of emergency mode thermostat			
Miscellaneous				
	Guarantee			

Contact information

AT **KNV Energietechnik GmbH**, Gahberggasse 11, 4861 Schörfling

Tel: +43 (0)7662 8963-0 Fax: +43 (0)7662 8963-44 E-mail: mail@knv.at www.knv.at

CH **NIBE Wärmetechnik AG**, Winterthurerstrasse 710, CH-8247 Flurlingen

Tel: (52) 647 00 30 Fax: (52) 647 00 31 E-mail: info@nibe.ch www.nibe.ch

CZ **Druzstevni zavody Drazice s.r.o**, Drazice 69, CZ - 294 71 Benatky nad Jizerou

Tel: +420 326 373 801 Fax: +420 326 373 803 E-mail: nibe@nibe.cz www.nibe.cz

DE **NIBE Systemtechnik GmbH**, Am Reiherpfahl 3, 29223 Celle

Tel: 05141/7546-0 Fax: 05141/7546-99 E-mail: info@nibe.de www.nibe.de

DK **Vølund Varmeteknik**, Filial af NIBE AB, Brogårdsvej 7, 6920 Videbæk

Tel: 97 17 20 33 Fax: 97 17 29 33 E-mail: info@volundvt.dk www.volundvt.dk

FI **NIBE – Haato OY**, Valimotie 27, 01510 Vantaa

Puh: 09-274 697 0 Fax: 09-274 697 40 E-mail: info@haato.com www.haato.fi

GB **NIBE Energy Systems Ltd**, 3C Broom Business Park, Bridge Way, Chesterfield S41 9QG

Tel: 0845 095 1200 Fax: 0845 095 1201 E-mail: info@nibe.co.uk www.nibe.co.uk

NL **NIBE Energietechniek B.V.**, Postbus 2, NL-4797 ZG WILLEMSTAD (NB)

Tel: 0168 477722 Fax: 0168 476998 E-mail: info@nibenl.nl www.nibenl.nl

NO **NIBE AB**, Fekjan 15F, 1394 Nesbru

Tel: 22 90 66 00 Fax: 22 90 66 09 E-mail: info@nibe.se www.nibevillavarme.no

PL **NIBE-BIAWAR Sp. z o. o.** Aleja Jana Pawła II 57, 15-703 BIAŁYSTOK

Tel: 085 662 84 90 Fax: 085 662 84 14 E-mail: sekretariat@biawar.com.pl www.biawar.com.pl

SE **NIBE AB Sweden**, Box 14, Järnvägsgatan 40, SE-285 21 Markaryd

Tel: +46-(0)433-73 000 Fax: +46-(0)433-73 190 E-mail: info@nibe.se www.nibe.se

2 Delivery and handling

Transport

F1245 should be transported and stored vertically in a dry place. When being moved into a building, F1245 may be leant back 45 °. **Note!** Can be tail heavy.

If the cooling module is pulled out and transported upright, F1245 can be transported on its back.





Pulling out the cooling module

To simplify transport and service, the heat pump can be separated by pulling the cooling module out from the cabinet.

See page 65 for instructions about the separation.

Assembly

- Position the heat pump on a firm base that can bear its weight, preferably on a concrete floor or foundation. Use the heat pump's adjustable feet to obtain a horizontal and stable set-up.
- The area where the heat pump is located must be equipped with floor drainage.
- Install with its back to an outside wall, ideally in a room where noise does not matter, in order to eliminate noise problems. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem.
- Wherever the unit is located, walls to sound sensitive rooms should be fitted with sound insulation.
- Route pipes so they are not fixed to an internal wall that backs on to a bedroom or living room.



Installation area

Leave a space of 800 mm in front of the heat pump. Approx 50 mm free space is required in order to open the side hatches. The hatches do not need to be opened during service, all service on F1245 can be carried out from the front.



*Depending on routing of supply cables and pipes.

** A normal installation needs 300 - 400 mm (any side) for connection of equipment, i.e. level vessel, valves and electrical equipment.

Supplied components



Outside sensor



Current sensor



Indoor sensor



Level vessel

Safety valve (3 bar)

O-rings

Particle filter



Conex connectors

5-10 kW

2 x (ø28 x G25)

2 x (ø22 x G20)

12 kW

4 x (ø28 x G25)

Location

The enclosed kit is located on the packaging for the heat pump.

Removing the covers

Front cover



1. Remove the screws from the lower edge of the front cover.
2. Lift the cover out at the bottom edge and up.

Side covers



The side covers can be removed to facilitate the installation.

1. Remove the screws from the upper and lower edges.
2. Twist the cover slightly outward.
3. Move the cover backwards and slightly to the side.
4. Pull the cover to one side.
5. Pull the cover forwards.

Removing parts of the insulation

Parts of the insulation can be removed to facilitate the installation.

Insulation, top

1. Disconnect the cable from the motor and remove the motor from the shuttle valve as illustrated.



2. Grip the handle and pull straight out as illustrated.



Insulation, immersion heater

NOTE

Electrical installation and service must be carried out under the supervision of a qualified electrician. Electrical installation and wiring must be carried out in accordance with the stipulations in force.

1. Remove the cover of the junction box according to the description on page 19.
2. Grip the handle and pull the insulation carefully towards you as illustrated.



3 The heat pump design



View from above



Pipe connections

XL 1	Connection, heating medium flow
XL 2	Connection, heating medium return
XL 3	Connection, cold water
XL 4	Connection, hot water
XL 5	Connection, VVC*
XL 6	Connection, brine in
XL 7	Connection, brine out

* Only applies to enamelled or stainless steel vessels.

HVAC components

QM 22	Venting, coil
QM 32	Shut off valve, heating medium return
QM 33	Shut off valve, brine out
QM 34	Shut-off valve, brine in
QN 10	Shuttle valve, climate system/water heater
WP 4	Pipe connection, heating medium flow

Sensors etc.

BT 1	Outside sensor
BT 2	Temperature sensors, heating medium flow
BT 6	Temperature sensor, hot water charging
BT 7	Temperature sensor, hot water top

Electrical components

AA 4	Display unit
	AA4-XJ3 USB outlet (no function)
	AA4-XJ4 Service outlet (No function)
EB 1	Immersion heater
FR 1	Sacrificial anode*
SF 1	Switch

* Only heat pump with enamelled vessel.

Miscellaneous

PF 1	Rating plate
PF 2	Type plate, cooling section
PF 3	Serial number plate
UB 1	Cable gland, incoming electricity
UB 2	Cable gland
UB 3	Cable gland, rear side, sensor

Designations in component locations according to standard IEC 62400.

Electrical cabinets



Electrical components

AA 1 Immersion heater card
AA 2 Base card
AA 3 Input circuit board
AA 8 Sacrificial anode card*
FA 1 Miniature circuit-breaker
FB 1 Motor cut-out**
FD 1 Temperature limiter/Emergency mode thermostat

* Only heat pump with enamelled vessel.

** 1x230 V, 3x230 V 6-10 kW has auxiliary switch for motor cut-out.

Designations in component locations according to standard IEC 62400.



1x230 V 5-12kW



3x400 V 6-12 kW



3x230 V 6-8 kW



3x230 V 10 kW

Electrical components

AA 10 Soft-start card
CA 1 Capacitor
FB 1 Motor cut-out**
QA 10 Contactor, compressor
QA 30 Soft-starter
RF 1 Suppression capacitor
X 301 Terminal block
X 302 Terminal block

** 1x230 V, 3x230 V 6-10 kW has auxiliary switch for motor cut-out.

Designations in component locations according to standard IEC 62400.

Cooling section









Pipe connections

XL 20 Service connection, high pressure
XL 21 Service connection, low pressure

HVAC components

GP 1 Circulation pump
GP 2 Brine pump
QM 1 Drainage, climate system
QM 2 Draining, brine side

Sensors etc.

BP 1 High pressure pressostat
BP 2 Low pressure pressostat
BT 3 Temperature sensors, heating medium return
BT 10 Temperature sensor, brine in
BT 11 Temperature sensor, brine out
BT 12 Temperature sensor, condenser supply line
BT 14 Temperature sensor, hot gas
BT 15 Temperature sensor, fluid pipe
BT 17 Temperature sensor, suction gas

Electrical components

AA 100 Joint card
EB 10 Compressor heater

Cooling components

EP 1 Evaporator
EP 2 Condenser
GQ 10 Compressor
HS 1 Drying filter
QN 1 Expansion valve

Designations in component locations according to standard IEC 62400.

4 Pipe connections

General

Pipe installation must be carried out in accordance with current norms and directives. F1245 can operate with a return temperature of up to 58 °C and an outgoing temperature from the heat pump of 70 (65 °C with only the compressor).

F1245 is not equipped with shut off valves; these must be installed outside the heat pump to facilitate any future servicing.

NOTE

The pipe system needs to be flushed out before the heat pump is connected so that debris cannot damage component parts.

Symbol key

Symbol	Meaning
	Shut-off valve
	Non-return valve
	Safety valve
	Trim valve
	Temperature sensor
	Level vessel
	Expansion vessel
	Pressure gauge
	Circulation pump
	Shunt / shuttle valve
	Particle filter
	Auxiliary relay
	Fan
	Compressor
	Heat exchanger

System diagram

F1245 consists of a heat pump, water heater, electrical module, circulation pumps and a control system. F1245 is connected to the brine and heating medium circuits.

In the heat pump evaporator, the brine (water mixed with anti-freeze, glycol or ethanol) releases its energy to the refrigerant, which is vaporised in order to be compressed in the compressor. The refrigerant, of which the temperature has now been raised, is passed to the condenser where it gives off its energy to the heating medium circuit and, if necessary, to the water heater. If there is a greater need for heating/hot water than the compressor can provide there is an integrated immersion heater.



XL 1	Connection, heating medium flow
XL 2	Connection, heating medium return
XL 3	Connection, cold water
XL 4	Connection, hot water
XL 6	Connection, brine in
XL 7	Connection, brine out

Dimensions and pipe connections



Pipe dimensions

Connection		5-10 kW	12 kW
(XL6)/(XL7) Brine in/out ext Ø	(mm)	28	
(XL1)/(XL2) Heating medium flow/return ext Ø	(mm)	22	28
(XL3)/(XL4) Cold/hot water Ø	(mm)	22	

* Can be angled for side connection.

Brine side

Collector

Type	Surface soil heat, recommended collector length (m)	Rock heat, recommended active drilling depth (m)
5 kW	200-300	70-90
6 kW	250-400	90-110
8 kW	325-2x250	120-140
10 kW	400-2x300	140-170
12 kW	2x250-2x350	160-190

Applies to PEM hose 40x2.4 PN 6.3.

These are rough example values. At installation the correct calculations must be made according to local conditions.

Caution

The length of the collector hose varies depending on the rock/soil conditions, climate zone and on the climate system (radiators or underfloor heating).

Max length per coil for the collector should not exceed 400 m.

In those cases where it is necessary to have several collectors, these should be connected in parallel with the possibility for adjusting the flow of the relevant coil.

For surface soil heat, the hose should be buried at a depth determined by local conditions and the distance between the hoses should be at least 1 metre.

For several bore holes, the distance between the holes must be determined according to local conditions.

Ensure the collector hose rises constantly towards the heat pump to avoid air pockets. If this is not possible, airvents should be used.

As the temperature of brine system can fall below 0 °C it must be protected against freezing down to -15 °C. 1 litre of ready mixed brine per meter of collector hose (applies when using PEM-hose 40x 2.4 PN 6.3) is used as a guide value when making the volume calculation.

Side connection

It is possible to angle the brine connections, for connection to the side instead of top connection.

To angle out a connection:

1. Disconnect the pipe at the top connection.
2. Angle the pipe in the desired direction.

3. If necessary, cut the pipe to the desired length.

Connecting the brine side

- Insulate all indoor brine pipes against condensation.
- The level vessel must be installed as the highest point in the brine system on the incoming pipe before the brine pump (Alt. 1).

  If the level vessel cannot be placed at the highest point an expansion vessel must be used (Alt. 2).

NOTE

Note that condensation may drip from the level vessel. Position the vessel so that this does not harm other equipment.

- Details of the antifreeze used must be shown on the level vessel.
- Install the supplied safety valve under the level vessel as illustrated. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost proof.
- Install shut off valves as close to the heat pump as possible.
- Fit the supplied particle filter on the incoming pipe.

In the case of connection to an open groundwater system, an intermediate frost-protected circuit must be provided, because of the risk of dirt and freezing in the evaporator. This requires an extra heat exchanger.



Hot water heater

Connecting the hot water heater

- The hot water heater in the heat pump must be supplied with necessary set of valves.
- The mixing valve must be installed if the setting is changed so that the temperature can exceed 60 °C. The setting is made in menu 5.1.1 (page 59)
- The safety valve must have a maximum 10.0 bar opening pressure and be installed on the incoming domestic water line as illustrated. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost proof.



Heating medium side

Connecting the climate system

A climate system is a system that regulates indoor comfort with the help of the control system in F1245 and for example radiators, underfloor heating/cooling, fan convectors etc.

- Install all required safety devices, shut-off valves (as close to the heat pump as possible), and particle filter.
- The safety valve must have a maximum 2.5 bar opening pressure and be installed on the outgoing heating medium as illustrated. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost proof.
- When connecting to a system with thermostats on all radiators, a relief valve must be fitted, or some of the thermostats must be removed to ensure sufficient flow.

Docking alternatives

F1245 can be connected in several different ways, some of which are shown below.

Further option information is available at www.nibe.eu and in the respective assembly instructions for the accessories used. See page 71 for a list of the accessories that can be used with F1245.

Extra electric hot water heater

The heat pump should be supplemented with an electric water heater, for example NIBE COMPACT, if a whirlpool or other significant consumer of hot water is installed.

- The valve connection on COMPACT can be separated. The mixing valve remains on COMPACT and the remaining valve connector can be used for incoming cold water in F1245.



Buffer vessel

If the climate system volume is too small for the heat pump output, the radiator system can be supplemented with a buffer vessel, for example NIBE UKV.



Ventilation recovery

The installation can be supplemented with the exhaust air module NIBE FLM to provide ventilation recovery.

- Pipes and other cold surfaces must be insulated with diffusion-proof material to prevent condensation.
- The brine system must be supplied with a pressure expansion vessel (CM3). If there is a level vessel (CM2) this should be replaced.



Free cooling

The installation can be supplemented with fan convectors, for example, in order to allow connections for free cooling (PK 4).

- Pipes and other cold surfaces must be insulated with diffusion-proof material to prevent condensation.
- Where the cooling demand is high, fan convectors with drip trays and drain connection are needed.
- The brine system must be supplied with a pressure expansion vessel (CM3). If there is a level vessel (CM2) this should be replaced.



Under floor heating systems

The external circulation pump is dimensioned for the under floor heating system's demand.



Two or more climate systems

When more than one climate system, with a lower temperature, is to be heated up, the following connection can be used. The shunt valve lowers the temperature to, for example, the under floor heating system.

The ECS 40 accessory is required for this connection.



Ground water system

An intermediate heat exchanger is used to protect the heat pump's exchanger from dirt. The water is released into a buried filtration unit or a drilled well. See page 25 for more information about connecting a ground water pump.



Pool

Charging of the pool is controlled by the pool sensor. In the case of low pool temperatures, the shuttle valve reverses direction and opens towards the pool exchanger. The POOL 40 accessory is required for this connection.



5 Electrical connections

General

All electrical equipment, except the outdoor sensors, room sensors and the current sensors are ready connected at the factory.

- Disconnect the heat pump before insulation testing the house wiring.
- F1245 is not connectable between 1 phase and 3 phase, neither is it connectable between 3x230V and 3x400V.
- If the building is equipped with an earth-fault breaker, F1245 should be equipped with a separate one.
- If a miniature circuit breaker is used this should have at least motor characteristic "C". See page 73 for fuse size.
- For wiring diagrams for the heat pump, see separate installation handbook for wiring diagrams.
- Communication and sensor cables to external connections must not be laid close to high current cables.
- The minimum area of communication and sensor cables to external connections must be 0.5 mm² up to 50 m, for example EKKX or LiYY or equivalent.

NOTE

The switch (SF1) must not be moved to "I" or "⚠" until the boiler has been filled with water. Otherwise the temperature limiter, thermostat, compressor and the immersion heater can be damaged.

NOTE

Electrical installation and service must be carried out under the supervision of a qualified electrician. Electrical installation and wiring must be carried out in accordance with the stipulations in force.

Miniature circuit-breaker

The heat pump and a large proportion of its internal components are internally fused by a miniature circuit breaker (FA1).

Temperature limiter

The temperature limiter (FD1) cuts the current supply to the electrical addition if the temperature rises between 90 and 100°C and can be manually reset.

Resetting

The temperature limiter (FD1) is accessible behind the front cover. Reset the temperature limiter by pressing the button (FD1-SF2) using a small screwdriver.

Motor cut-out

Motor protection breaker (FB1) cuts the power to the compressor if the current is too high.

Resetting

The motor protection breaker (FB1) is accessible behind the front cover. The breaker is reset by twisting the control knob to horizontal position.

Caution

Check the miniature circuit-breaker, temperature limiter and motor protection breaker. They may have tripped during transportation.

Cable lock

Use a suitable tool to release/lock cables in the heat pump terminal blocks.





Accessibility, electrical connection

The plastic cap of the electrical boxes is opened using a screwdriver.

NOTE

The cover for the input card is opened without a tool.

Removing the cover, input circuit board



1. Push the piece of plastic down.
2. Angle out the cover and remove it.

Removing the cover, immersion heater circuit board



1. Insert the screwdriver (A) and pry the piece of plastic carefully downwards (B).
2. Angle out the cover and remove it.

Removing the cover, base board

Caution

To remove the cover for the base board, the cover for the input circuit board must first be removed.



1. Disconnect the switches using a screwdriver.
2. Insert the screwdriver (A) and pry the piece of plastic carefully downwards (B).
3. Angle out the cover and remove it.

Connections

NOTE

To prevent interference, unscreened communication and/or sensor to external connections cables must not be laid closer than 20 cm to high voltage cable when cable routing.

Power connection

F1245 must be installed via an isolator switch with a minimum breaking gap of 3mm. Minimum cable area must be dimensioned according to the fuse rating used. Incoming electricity is connected on terminal block (X1) on the immersion heater card (AA1). The cable must be routed through the lower section of the junction box. Conductors must be stripped approx. 12 - 13 mm.

NOTE

F1245 is not connectable between 1 phase and 3 phase, neither is it connectable between 3x230V and 3x400V.

Connection 3x400V



Connection 3x230V



Connection 1x230V



NOTE

F1245-12 contains scroll compressor, which means that it is important that electrical connections are made with the correct phase sequence. With the incorrect phase sequence, the compressor does not start and an alarm is displayed.

If separate supply to the compressor and immersion heater is required, see section "Blocking of additional heat and/or compressor" on page 24.

Connecting external operating voltage for the control system

NOTE

Only applies to power connection of 3x400V.

If you wish to connect external operating voltage for the control system to F1245 on the immersion heater circuit board (AA1) the edge connector at AA1:X2 must be moved toAA1:X9 (as illustrated).

Operating voltage (1x230V+N+PE) is connected to AA1:X11 (as illustrated).



1x230V+N+PE operating voltage

Outside sensor

Install the outside temperature sensor (BT1) in the shade on a wall facing north or north-west, so it is unaffected by the morning sun.

Connect the sensor to terminal block X6:1 and X6:2 on the input card (AA3). Use a 2 core cable of at least 0.5 mm² cable area.

If a conduit is used it must be sealed to prevent condensation in the sensor capsule.





Room sensor

F1245 is supplied with a room sensor (RTS40). The room sensor has three functions:

1. Show current room temperature in the heat pump's display.
2. Option of changing the room temperature in °C.
3. Makes it possible to change/stabilise the room temperature.

Install the sensor in a neutral position where the set temperature is required. A suitable location is on a free inner wall in a hall approx. 1.5 m above the floor. It is important that the sensor is not obstructed from measuring the correct room temperature by being located, for example, in a recess, between shelves, behind a curtain, closed radiator thermostats, above or close to a heat source, in a draft from an external door or in direct sunlight.

The heat pump operates without the sensor, but if one wishes to read off the accommodation's indoor temperature in F1245's display the sensor must be installed. Connect the room sensor to X6:3 and X6:4 on the input circuit board (AA3).

If the sensor is to be used to change the room temperature in °C and/or to change/stabilise the room temperature, the sensor must be activated in menu 1.9.4.

If the room sensor is used in a room with under floor heating it should only have an indicatory function, not control of the room temperature.





Caution

Changes of temperature in accommodation take time. For example, short time periods in combination with underfloor heating will not give a noticeable difference in room temperature.

Settings



Electrical addition - maximum output

On delivery, the immersion heater is connected for a maximum of 9 kW (at 3x400V and 3x230V) or 7 kW (at 1x230V).

The immersion heater output is divided into four steps, according to the table below.

Setting of electrical steps

Setting maximum output in the electrical addition is done in menu 5.2.

The tables display the total phase current for the immersion heater.

3x400V

Max electrical addition (kW)	Electrical step	Max phase current L1(A)	Max phase current L2(A)	Max phase current L3(A)
0	0	0	0	0
2	1	0	8.7	0
4	2	0	8.7	8.7
6	3	8.7	8.7	8.7
9	4	8.7	16.2	16.2

3x230V

Max electrical addition (kW)	Electrical step	Max phase current L1(A)	Max phase current L2(A)	Max phase current L3(A)
0	0	0	0	0
2	1	-	-	-
4	2	-	-	-
6	3	-	-	-
9	4	-	-	-

1x230V

Max electrical addition (kW)	Electrical step	Max phase current L1(A)
0	0	0
2	1	8.7
4	2	17.4
6	3	26.1
7	4	30.4

If the current sensors are connected, the heat pump monitors the phase currents and allocates the electrical steps automatically to the least loaded phase.

Emergency mode

When the heat pump is set to emergency mode (SF1 is set to ⚠) only the most necessary functions are activated.

- The compressor is switched off. Hot water is not produced and heating is handled by the immersion heater.
- The load monitor is not connected.

NOTE

Switch (SF1) must not be moved to "I" or "⚠" until F1245 has been filled with water. Otherwise the temperature limiter, thermostat, compressor and the immersion heater can be damaged.

Power in emergency mode

The immersion heater's output in emergency mode is set with a dipswitch (SF2) on the immersion heater circuit board (AA1) according to the table below. Factory setting is 6 kW.

3x400V	1	2	3	4	5	6
2 kW	off	off	off	off	on	off
4 kW	off	off	on	off	on	off
6 kW	on	off	on	off	on	off
9 kW	on	off	on	on	on	on

3x230V	1	2	3	4	5	6
2 kW	off	off	off	on	off	off
4 kW	off	off	on	on	off	off
6 kW	on	on	off	on	off	off
9 kW	on	on	on	on	off	off

1x230V	1	2	3	4	5	6
2 kW	off	off	off	off	on	off
4 kW	off	off	on	off	on	off
6 kW	on	off	on	off	on	off
7 kW	on	off	on	on	on	on

3x400V/1x230V



3x230V



The image shows the dip-switch (AA1-SF2) in the factory setting, that is 6 kW.

Emergency mode thermostat

The supply temperature is set in emergency mode using a thermostat (FD1-BT30). It can be set to 35 (pre-set, for example underfloor heating) or 45 °C (for example radiators).



Optional connections

Load monitor

NOTE

The load monitor has no function in a 1-phase installation.

When many power consumers are connected in the property at the same time as the electric addition is operating, there is a risk of the property's main fuse tripping. The heat pump has integrated load monitors that control the electrical steps for the electrical addition by redistributing the power between the different phases or disengaging. Reconnection occurs when other current consumption is reduced.

Connecting current sensors

A current sensor should be installed on each incoming phase conductor in to the distribution box to measure the current. The distribution box is an appropriate installation point.

Connect the current sensors to a multi-core cable in an enclosure next to the distribution box. Use a multi-core cable of at least 0.5 mm² from the enclosure to the heat pump.

Connect the cable to the input card (AA3) on terminal block X4:1-X4:4 where X4:1 is the common terminal block for the three current sensors.

The size of the property's main fuse is set in menu 5.1.12.



External connection options

If an external switch function is connected to F1245, the function for use input or output must be selected in menu 5.4, see page 61.

Selectable inputs on the input card for these functions are AUX1 (X6:9-10), AUX2 (X6:11-12), AUX3 (X6:13-14), AUX4 (X6:15-16) and AUX5 (X6:17-18). Selectable outputs are AA3:X7.





The example above uses the inputs AUX3 (X6:13-14) and AUX4 (X6:15-16) on the input circuit board (AA3).

Caution

Some of the following functions can also be activated and scheduled via menu settings.

Blocking of additional heat and/or compressor

In those cases blocking of addition and/or compressor is used, this can be connected to terminal block (X6) on the input card (AA3), which is positioned behind the front cover.

The additional heat and/or the compressor are disconnected by connecting a potential free switch function to the input selected in menu 5.4, see page 61.

Blocking of addition and compressor can be combined.

A closed contact results in the electrical output being disconnected.

Contact for activation of "temporary lux"

An external contact function can be connected to F1245 for activation of "temporary lux", The contact must be potential free and connected to the selected input (menu 5.4) on terminal block X6 on the input card (AA3).

"temporary lux" is activated for the time that the contact is connected.

Contact for activation of "external adjustment"

An external contact function can be connected to F1245 to change the supply temperature and the room temperature.

When the switch is closed the desired temperature is set in °C (if the room sensor is connected and activated). If a room sensor is not connected or activated the desired change of an already set heat curve and offset with the number of steps selected is set. The value is adjustable between -10 and +10.

- ***climate system 1***

  The contact must be potential free and connected to the selected input (menu 5.4) on terminal block X6 on the input card (AA3).

  The value for the change is set in menu 1.9.2, "external adjustment".

- ***climate system 2 to 4***

  External adjustment for climate systems 2 to 4 require accessories (ECS 40).

  See the accessory's installer handbook for installation instructions.

Contact for activation of fan speed

Caution

The external contact function functions only if the accessory FLM is installed and activated.

An external contact function can be connected to F1245 for activation of one of the four fan speeds. The contact must be potential free and resprung and connected into the selected input (menu 5.4) on terminal block X6 on the input card (AA3). When the contact is closed for at least one second the selected fan speed is activated. The return to normal speed occurs according to the time set in menu 1.9.6.

NV 10, pressure/level/flow monitor brine

If the level sensor (accessory NV10) is desired for the brine installation it can be connected on the selected input (menu 5.4) on terminal block X6 on input card (AA3).

Pressure and flow sensors can also be connected to the input.

For function the input must be connected during normal operation.

Indication of buzzer alarm / Control of ground water pump / Cooling mode indication / Hot water circulation

It is possible to have an external indication of the buzzer alarm, control of ground water pump, cooling mode indication (only if the accessory for cooling is present or if the heat pump has an integrated function for cooling) or control of the circulation pump for hot water circulation* through relay function via a potential free variable relay (max 2 A) on the input circuit board (AA3), terminal block X7.

If the buzzer alarm, ground water pump, cooling mode indication or hot water circulation* is connected to terminal block X7 it must be selected in menu 5.4, see page 61.

The buzzer alarm is connected and activated at the factory.

NOTE

An accessory card is required if the ground water pump, cooling mode indication* or hot water circulation pump** is connected to F1245 at the same time that the buzzer alarm is activated (see page 71).

* Only applies to enamelled or stainless steel vessels.



The picture shows the relay in the alarm position.

When switch (SF1) is in the "⏻" or "⚠" position the relay is in the alarm position.

Connecting accessories

Instructions for connecting accessories are in the installation instructions provided. See page 71 for the list of the accessories that can be used with F1245.

6 Commissioning and adjusting

Preparations

1. Check that the switch (SF1) is in position " ⏻".
2. Check that the temperature limiter FD1 has not tripped.
3. Check for water in the hot water heater and climate system.

Caution

Check the temperature limiter, motor protection and miniature circuit-breaker. They may have tripped during transportation.

Filling and venting

Filling the hot water heater

1. Open a hot water tap in the house.
2. Fill the hot water heater through the cold water connection (XL3).
3. When water comes out of the hot water tap, the hot water heater is full and the tap can be closed.

Filling and venting the climate system

Filling

1. Open the filling valve (external, not included with the product). Fill the coil in the hot water heater and the rest of the climate system with water.
2. Open the venting valve (QM22).
3. When the water that exits the venting valve (QM22) is not mixed with air, close the valve. After a while the pressure starts to rise.
4. Close the filling valve when the correct pressure is obtained.

Venting

1. Bleed the heat pump via the bleed valve (QM22) and the rest of the climate system via the relevant bleed valves.
2. Keep topping up and venting until all air has been removed and the pressure is correct.

TIP

If the heating medium pump (GP1) must be run during venting, it can be started via the start guide.

NOTE

The pipe from the coil in the container must be drained of water before air can be released. This means that the system is not necessarily vented despite the flow of water when the venting valve (QM22) is opened.

Filling and venting the brine system

When filling the brine system, mix the water with anti-freeze in an open container. The mixture should be protected against freezing down to about -15 °C. The brine is filled by connecting a filling pump.

1. Check the brine system for leakage.
2. Connect the filling pump and return line on the brine system's filler connector as illustrated.
3. If alternative 1 (level vessel) is used, close the valve under the level vessel (CM2).
4. Close the three way valve in the filler connector (accessory).
5. Open the valves on the filler connector.
6. Start the filling pump.
7. Fill until liquid enters the return pipe.
8. Vent the brine system with venting valve on F1245.
9. Close the valves on the filler connector.
10. Open the three way valve in the filler connector.
11. If alternative 1 (level vessel) is used, open the valve under the level vessel (CM2).

TIP

If the brine pump (GP2) must be run during venting, it can be started via the start guide.





XL 1	Connection, heating medium flow
XL 2	Connection, heating medium return
XL 3	Connection, cold water
XL 4	Connection, hot water
XL 6	Connection, brine in
XL 7	Connection, brine out

Symbol key

Symbol	Meaning
	Shut-off valve
	Safety valve
	Level vessel
	Expansion vessel
Ⓟ	Pressure gauge
	Particle filter

Start guide

NOTE

There must be water in the climate system before the switch is set to "**I**".

1. Turn the heat pump's switch (SF1) to "**I**".
2. Follow the instructions in the start guide in the heat pump display. If the start guide does not start when you start the heat pump, start it manually in menu 5.7.

Commissioning

The first time the heat pump is started a start guide is started. The start guide instructions state what needs to carried out at the first start together with a run through of the heat pump's basic settings.

The start guide ensures that the start-up is carried out correctly and cannot be bypassed. The start guide can be started later in menu 5.7.

Operation in the start guide

Arrows to scroll through window in start guide

1. Turn the control knob until the arrow in the top left corner (at the page number) has been marked.
2. Press the OK button to access the next step in the start guide.

See page 39 for a more in-depth introduction to the heat pump's control system.

The start guide will be described under the following points step-by-step.

1. Selection of language



Choose the language that you want the information to be displayed in here.

Change language as follows:

1. Turn the control knob until the language you require is marked.
2. Press the OK button.
3. Turn the control knob until the arrow in the top left corner (at the page number) has been marked.
4. Press the OK button to access the next step in the start guide.

2. Information


2/21
start guide 5.7
Welcome to the start guide for your heat pump.
As long as the start guide is active, no function in the heat pump will start automatically.
The guide will show up with each restart of the heat pump until it is deselected on the last page.

Information about the start guide for the heat pump is shown here.

3. Setting "operating mode brine pump"



op. mode

Setting range: intermittent, continuous, 10 days continuous

Default value: intermittent

Set the operating mode of the brine pump here.

intermittent: The brine pump starts 20 seconds before and stops at the same time as the compressor.

continuous: Continuous operation.

10 days continuous: Continuous operation for 10 days. Then the pump shifts to intermittent operation.

TIP

You can use "10 days continuous" at start-up to obtain continuous circulation during a start-up time in order to make it easier to bleed the system.

4. Setting "op. mod heat med pump"



op. mode

Setting range: auto, intermittent, continuous,

Default value: auto

Set the operating mode of the heating medium pump here.

auto: The heating medium pump runs according to the current operating mode for F1245.

intermittent: The heating medium pump starts 20 seconds before and stops at the same time as the compressor.

continuous: Continuous operation.

5. Setting "internal electrical addition"



max. electric power

Setting range: 0 - 9 kW

Default values: 3 kW

fuse size

Setting range: 1 - 200 A

Default values: 16 A

Set the max. electric power of the internal electrical addition in F1245 and the fuse size for the installation.

6. System settings



Make different system settings for the heat pump here, e.g. which accessories are installed.

There are two ways of activating connected accessories. You can either mark the alternative in the list or use the automatic function "search installed acc.".

search installed acc.

Mark “search installed acc." and press the OK button to automatically find connected accessories for F1245.

Caution

"level sensor" are not found automatically but must be ticked off by hand.

7. Setting NIBE FLM



This part of the start guide is only displayed if the alternative is selected in a previous menu and the accessory is installed.

time between defrosts

Setting range: 1 – 30 h

Default value: 10 h

months btwn filter alarms

Setting range: 1 – 12

Default value: 3

continuous pump op.: Select for continuous operation of the circulation pump in NIBE FLM.

time between defrosts: Set the minimum time that must pass between defrostings of the heat exchanger in NIBE FLM.

When the exhaust air module is in operation the heat exchanger is cooled so that ice builds up on it. When too much ice builds up the heat transfer capacity of the heat exchanger is reduced and defrosting is required. Defrosting warms up the heat exchanger so that the ice melts and runs off via the condensation hose.

months btwn filter alarms: Set how many months should pass before the heat pump informs that it is time to clean the filter in NIBE FLM.

Clean NIBE FLM's two air filters regularly, how often depends on the amount of dust in the ventilation air.

8. Setting the fan speed exhaust air



This part of the start guide is only displayed if the alternative is selected in a previous menu and the accessory is installed.

normal and speed 1-4

Setting range: 0 – 100 %

Set the speed for the five different selectable speeds for the fan here.

Caution

Too low a value can damage the house in the long term.

10. Setting "shunt controlled add. heat"



This part of the start guide is only displayed if the alternative is selected in a previous menu and the accessory is installed.

minimum running time

Setting range: 0 – 48 h

Default value: 12 h

min temp.

Setting range: 5 – 90 °C

Default value: 55 °C

mixing valve amplifier

Setting range: 0.1 –10.0

Default value: 1.0

mixing valve step delay

Setting range: 10 – 300 s

Default values: 30 s

Set the minimum run time and the minimum temperature for external addition with shunt here. External addition with shunt is then for example wood/oil/gas/pellet boiler.

For the shunt you can set shunt amplification and shunt waiting time.

See the accessory installation instructions for function description.

11. Setting "extra climate system"



This part of the start guide is only displayed if the alternative is selected in a previous menu and the accessory is installed.

mixing valve amplifier

Setting range: 0.1 –10.0

Default value: 1.0

mixing valve step delay

Setting range: 10 – 300 s

Default values: 30 s

Set the shunt amplification and shunt waiting time for the different extra climate systems that are installed.

See the accessory installation instructions for function description.

12. Setting pool heating



This part of the start guide is only displayed if the alternative is selected in a previous menu and the accessory is installed.

start temp

Setting range: 15.0 - 70.0 °C

Default value: 22.0 °C

stop temperature

Setting range: 15.0 - 70.0 °C

Default value: 24.0 °C

Select whether the pool control is to be activated and within what temperatures (start and stop temperature) pool heating must occur.

When the pool temperature drops below the set start temperature and there is no hot water or heating requirement, F1245 starts pool heating.

Untick "activated" to switch off the pool heating.

Caution

The start temperature cannot be set to a value that is higher than the stop temperature.

13. Setting cooling function



This part of the start guide is only displayed if the alternative is selected in a previous menu. In addition, it requires either the accessory to be installed or that F1245 has an integrated function for cooling.

min. temp. cooling flow

Setting range: 5 - 50 °C

Default value: 10

cooling flow temp. at +20 °C

Setting range: 5 - 50 °C

Default value: 20

cooling flow temp. at +30 °C

Setting range: 5 - 50 °C

Default value: 15

time betw. switch heat/cool

Setting range: 0 - 48 h

Default value: 2

heat at room under temp.

Setting range: 0.5 - 10.0 °C

Default value: 1.0

cool at room over temp.

Setting range: 0.5 - 10.0 °C

Default value: 1.0

You can use F1245 to cool the house during hot periods.

14. Checking the measurement values from sensor


14/21
start guide 5.7
Check whether the following externally installed sensors are within their permitted values.
outdoor temp.(EB1-BT1) -5.6 °C
external flow temp.(EB1-BT25) 30.7 °C
boiler sensor (EM1-BT52) 75.0 °C
pool temperature(EPx-BT51) 26.5 °C
heat medium flow(EB21-BT2) 0.0 °C

Check here whether the selected externally mounted sensor shows permitted values for the installation.

15. Setting time and date



Set time and date and display mode here.

16. Setting min. flow line temp.



climate system

Setting range: 15 – 50 °C

Default value: 15 °C

Set the minimum temperature on the supply temperature to the climate system. This means that F1245 never calculates a temperature lower than that set here.

If there is more than one climate system the setting can be made separately for each system.

TIP

The value can be increased if you have, for example, a cellar that you always want to heat, even in summer.

17. Setting max. flow line temp.



climate system

Setting range: 15 – 80 °C

Default value: 60 °C

Set the maximum supply temperature for the climate system here. If the installation has more than one climate system, individual maximum supply temperatures can be set for each system.

Caution

Underfloor heating systems are normally max flow line temperature set between 35 and 45 °C.

Check the max temperature for your floor with your floor supplier.

18. Setting the heat curve



At basic setting the climate system "heating curve" and "temperature" (heating curve offset) must be changed.

Further information on how to set the heating curve can be found on page 47.

Setting automatic heating controls with diagram

The diagrams are based on the dimensioned outdoor temperature in the area and the dimensioned supply temperature of the climate system. When these two values "meet", the heating control's curve slope can be read. This is set under "heating curve" in menu 1.9.1.







19. Setting operating mode



op. mode

Setting range: auto, manual, add. heat only

Default value: auto

functions

Setting range: compressor, addition, heating, cooling

The heat pump operating mode is usually set to "auto". It is also possible to set the heat pump to "add. heat only", but only when an addition is used, or "manual" and select yourself what functions are to be permitted.

Change the operating mode by marking the desired mode and pressing the OK button. When an operating mode is selected it shows what in the heat pump is permitted (crossed out = not permitted) and selectable alternatives to the right. To select selectable functions that are permitted or not you mark the function using the control knob and press the OK button.

Operating mode auto

In this operating mode you cannot select which functions are to be permitted or not because it is handled automatically by the heat pump.

Operating mode manual

In this operating mode you can select what functions are permitted or not. You cannot deselect "compressor" in manual mode.

Operating mode add. heat only

Caution

If you choose mode "add. heat only" the compressor is deselected and there is a higher operating cost.

In this operating mode the compressor is not active and only additional heat is used. You can also choose to deactivate heating or cooling (only if accessory for cooling is available or if the heat pump has an integrated cooling function).

Functions

"**compressor**" is that which produces heating and hot water for the accommodation. You cannot deselect "compressor" in manual mode. If "compressor" is deselected, a symbol in the main menu on the heat pump symbol is displayed.

"**addition**" is what helps the compressor to heat the accommodation and/or the hot water when it cannot manage the whole requirement alone.

"**heating**" means that you get heat in the accommodation. You can deselect the function when you do not wish to have heating running.

"**cooling**" means that you get cooling in the accommodation in hot weather. You can deselect the function when you do not wish to have the cooling running. This alternative requires an accessory for cooling or if the heat pump has a built in function for cooling.

Caution

If you deselect "addition" it may mean that sufficient cooling in the accommodation is not achieved.

20. Filling in the checklist


20/21
start guide 5.7
Don't forget to fill in the check list in chapter 1 in both the Installer and User manual.
This is important since this data has to be stated in event of future services.

Do not forget to fill in the checklist on page 3 and in the user manual.

21. Complete the start guide


21/21
start guide 5.7
You have come to the last page of the start guide. Do you wish the start guide to start the next time the heat pump is restarted?
yes
no

Here you select whether to start the start guide the next time the heat pump is restarted.

Caution

If you choose "yes" this means that the next time the heat pump is started (e.g. after a power cut) it will not produce heat or hot water.

Post adjustment and venting

Pump capacity diagrams, collector side

To set the correct flow in the brine system the correct speed must be set for the brine pump.

The flow must have a temperature difference between brine out (BT11) and brine in (BT10) of 2 - 5 °C when the system is balanced (suitably 5 minutes after compressor start). Check these temperatures in menu 3.1 "service info" and adjust the brine pump (GP2) speed until the temperature difference is achieved. A high difference indicates a low brine flow and a low difference indicates a high brine flow.

Check that the correct program ("Proportional pressure") is set on the brine pump (GP2). Only the LED for "Proportional pressure" should light around the program selector. If it must be reset press the program selector repeatedly until the correct LED lights (see illustration).

Set the speed of the brine pump by pressing the "Increase" or "Reduce" button. Hold the "Increase" button to set "Max" speed.

Read off what speed the brine pump should have from the diagrams below.





F1245 5 kW

Available pressure, kPa
Electrical output, W



F1245 6 kW

Available pressure, kPa
Electrical output, W



F1245 8 kW

Available pressure, kPa
Electrical output, W



F1245 10 kW

Available pressure, kPa
Electrical output, W



F1245 12 kW

Available pressure, kPa
Electrical output, W



Pump capacity diagrams, heating medium side

To set the correct flow in the heating medium system the correct speed must be set for the heating medium pump in the different operating conditions.

The flow must have suitable temperature differential for the operating conditions, between the flow temperature (BT2) and the return line temperature (BT3) when house heating occurs (at floating condensation). Check these temperatures in menu 3.1 "service info" and adjust the heating medium pump (GP1) speed until the temperature difference is achieved. A high difference indicates a low heating medium flow and a low difference indicates a high heating medium flow.

Set the speed of the heating medium pump in menu 5.1.11, see page 60.

Read off what speed the heating medium pump should be from the diagrams below.

Available pressure
P Electrical output

F1245 5 kW

Available pressure, kPa
Electrical output, W



F1245 6 kW



F1245 8 and 12 kW



F1245 10 kW



Readjusting, venting, heat medium side

Air is initially released from the hot water and venting may be necessary. If gurgling sounds can be heard from the heat pump or climate system, the entire system will require additional venting.

Readjusting, venting, collector side

Level vessel



Check the fluid level in the level vessel (CM2). If the fluid level has dropped, top up the system.

1. Close the valve under the vessel.
2. Disconnect the connection on top of the vessel.
3. Fill with brine until approx 2/3 of the vessel is full.
4. Reconnect the connector at the top of the vessel.
5. Open the valve under the vessel.

The pressure is raised by closing the valve on the incoming main line when the brine pump (GP2) is running and the level vessel (CM2) is open, so that liquid is drawn down from the vessel.

Expansion vessel



If a pressure expansion vessel (CM3) is used instead of a level vessel, the pressure level is checked. If the pressure drops, the system should be replenished.

Post adjusting the room temperature

If the required room temperature is not obtained, readjustment may be necessary.

Cold weather conditions

- If the room temperature is too low, increase "heating curve" in menu 1.9.1, one step.
- If the room temperature is too high, reduce "heating curve" in menu 1.9.1, one step.

Warm weather conditions

- If the room temperature is too low, increase "temperature" (heating curve offset) in menu 1.1, one step.
- If the room temperature is too high, reduce "temperature" (heating curve offset) in menu 1.1, one step.

7 Control - Introduction

Display unit



A Display

Instructions, settings and operational information are shown on the display. The easy-to-read display and menu system, facilitates navigation between the different menus and options to set the comfort or obtain the information you require.

B Status lamp

The status lamp indicates the status of the heat pump. It:

- lights green during normal operation.
- lights yellow in emergency mode.
- lights red in the event of a deployed alarm.

C OK button

The OK button is used to:

- confirm selections of sub menus/options/set values/page in the start guide.

D Back button

The back button is used to:

- go back to the previous menu.
- change a setting that has not been confirmed.

E Control knob

The control knob can be turned to the right or left. You can:

- scroll in menus and between options.
- increase and decrease the values.
- change page in multiple page instructions (for example help text and service info).

F Switch (SF1)

The switch assumes three positions:

- On (I)
- Standby (⏻)
- Emergency mode (⚠) (see page 22)

Emergency mode must only be used in the event of a fault on the heat pump. In this mode, the compressor switches off and the immersion heater engages. The heat pump display is not illuminated and the status lamp illuminates yellow.

Menu system

When the door to the heat pump is opened, the menu system's four main menus are shown in the display as well as certain basic information.



Menu 1 - INDOOR CLIMATE

Setting and scheduling the indoor climate. See page 43.

Menu 2 - HOT WATER

Setting and scheduling hot water production. See page 51.

Menu 3 - INFO

Display of temperature and other operating information and access to the alarm log. See page 53.

Menu 4 - HEAT PUMP

Setting time, date, language, display, operating mode etc. See page 54.

Menu 5 - SERVICE

Advanced settings. These settings are not available to the end user. The menu is visible by pressing the Back button for 7 seconds. See page 58.



Operation

To move the cursor, turn the control knob to the left or the right. The marked position is always brighter and/or has a turned up tab.

Selecting menu

To advance in the menu system select a main menu by marking it and then pressing the OK button. A new window then opens with sub menus.

Select one of the sub menus by marking it and then pressing the OK button.

Selecting options



In an options menu the current selected option is indicated by a green tick.

To select another option:

1. Mark the applicable option. One of the options is pre-selected (white).
2. Press the OK button to confirm the selected option. The selected option has a green tick.

Setting a value



Values to be changed

To set a value:

1. Mark the value you want to set using the control knob.

2. Press the OK button. The background of the value becomes green, which means that you have accessed the setting mode.

3. Turn the control knob to the right to increase the value and to the left to reduce the value.

4. Press the OK button to confirm the value you have set. To undo and return to the original value, press the Back button.

Scroll through the windows

A menu can consist of several windows. Turn the control knob to scroll between the windows.

Current menu window

Number of windows in the

Scroll through the windows in the start guide

Arrows to scroll through window in start guide

1. Turn the control knob until the arrow in the top left corner (at the page number) has been marked.
2. Press the OK button to access the next step in the start guide.

Help menu

In many menus there is a symbol that indicates that extra help is available.

To access the help text:

1. Use the control knob to select the help symbol.
2. Press the OK button.

The help text often consists of several windows that you can scroll between using the control knob.

8 Control - Menus

Menu 1 - INDOOR CLIMATE

Overview

1 - INDOOR CLIMATE	1.1 - temperature	
	1.2 - ventilation *	
	1.3 - scheduling	1.3.1 - heating
		1.3.2 - cooling *
		1.3.3 - ventilation *
	1.9 - advanced	1.9.1 - heating curve
		1.9.2 - external adjustment
		1.9.3 - min. flow line temp.
		1.9.4 - room sensor settings
		1.9.5 - cooling settings *
		1.9.6 - fan return time *
		1.9.7 - own curve
		1.9.8 - point offset

* Accessory needed.

Sub-menus

For the menu INDOOR CLIMATE there are several sub-menus. Status information for the relevant menu can be found on the display to the right of the menus.

temperature Setting the temperature for the climate system. The status information shows the set values for the climate system. Tab for cooling system is only displayed if accessory for cooling are present or if the heat pump has the integrated cooling function.

ventilation Setting the fan speed. The status information shows the selected setting. This menu is only displayed if the exhaust air module is connected (accessory).

scheduling Scheduling heating, cooling and ventilation. Status information "set" is displayed if you set a schedule but it is not active now, "holiday setting" is displayed if the vacation schedule is active at the same time as the schedule (the vacation function is prioritised), "active" displays if any part of the schedule is active, otherwise it displays " off".

advanced Setting of heat curve, adjusting with external contact, minimum value of supply temperature, room sensor and cooling function.

Menu 1.1 - temperature

If the house has several climate systems, this is indicated on the display by a thermometer for each system.

If the heat pump has an accessory for cooling or integrated cooling function this is shown in the display with an extra tab.

Set the temperature (with room sensors installed and activated):

Setting range: 5 - 30 °C

Default value: 22

The value in the display appears as a temperature in °C if the heating system is controlled by a room sensor.

To change the room temperature, use the control knob to set the desired temperature in the display. Confirm the new setting by pressing the OK button. The new temperature is shown on the right-hand side of the symbol in the display.

Setting the temperature (without room sensors activated):

Setting range: -10 to +10

Default value: 0

The display shows the set values for heating (curve offset). To increase or reduce the indoor temperature, increase or reduce the value on the display.

Use the control knob to set a new value. Confirm the new setting by pressing the OK button.

The number of steps the value has to be changed to achieve a degree change of the indoor temperature depends on the heating unit. One step for under floor heating whilst radiators may require three.

Setting the desired value. The new value is shown on the right-hand side of the symbol in the display.

Caution

An increase in the room temperature can be slowed by the thermostats for the radiators or under floor heating. Therefore, open the thermostat valves fully, except in those rooms where a cooler temperature is required, e.g. bedrooms.

TIP

Wait 24 hours before making a new setting, so that the room temperature has time to stabilise.

If it is cold outdoors and the room temperature is too low, increase the curve slope in menu 1.9.1 by one increment.

If it is cold outdoors and the room temperature is too high, lower the curve slope menu 1.9.1 by one increment.

If it is warm outdoors and the room temperature is too low, increase the value in menu 1.1 by one increment.

If it is warm outdoors and the room temperature is too high, reduce the value in menu 1.1 by one increment.

Menu 1.2 - ventilation (accessory required)

Setting range: normal and speed 1-4

Default value: normal

The ventilation in the accommodation can be temporarily increased or reduced here.

When you have selected a new speed a clock starts a count down. When the time has counted down the ventilation speed returns to the normal setting.

If necessary, the different return times can be changed in menu 1.9.6.

The fan speed is shown in brackets (in percent) after each speed alternative.

TIP

If longer time changes are required use the holiday function or scheduling.

Menu 1.3 - scheduling

In the menu scheduling indoor climate (heating/cooling/ventilation) is scheduled for each weekday.

You can also schedule a longer period during a selected period (vacation) in menu 4.7.

Menu 1.3.1 - heating

Increases or decreases in the accommodation temperature can be scheduled here for up to three time periods per day. If a room sensor is installed and activated the desired room temperature (°C) is set during the time period. Without an activated room sensor the desired change is set (of setting in menu 1.1). A one degree change in room temperature requires one increment for under floor heating and approximately two to three increments for the radiator system.

If two settings conflict with each other a red exclamation mark is displayed at the end of the line.



Schedule: The schedule to be changed is selected here.

Activated: Scheduling for the selected period is activated here. Set times are not affected at deactivation.

System: Which climate system the schedule is for is selected here. This alternative is only displayed if more than one climate system is present.

Day: Select which day or days of the week the schedule is to apply to here. To remove the scheduling for a particular day, the time for that day must be reset by setting the start time to the same as the stop time. If the line "all" is used, all days in the period are set for these times.

Time period: The start and stop time for the selected day for scheduling are selected here.

Adjusting: How much the heating curve is to be offset in relation to menu 1.1 during scheduling is set here. If the rooms sensor is installed the desired room temperature is set in °C.

TIP

If you wish to set similar scheduling for every day of the week start by filling in "all" and then changing the desired days.

Caution

If the stop time is before the start time it means that the period extends past midnight.

Scheduling always starts on the date that the start time is set for.

Caution

Changes of temperature in accommodation take time. For example, short time periods in combination with underfloor heating will not give a noticeable difference in room temperature.

Menu 1.3.2 - cooling (accessory required)

Here you can schedule when cooling is permitted in the accommodation for up to two different time periods per day.

If two settings conflict with each other a red exclamation mark is displayed at the end of the line.

Schedule: The schedule to be changed is selected here.

Activated: Scheduling for the selected period is activated here. Set times are not affected at deactivation.

Day: Select which day or days of the week the schedule is to apply to here. To remove the scheduling for a particular day, the time for that day must be reset by setting the start time to the same as the stop time. If the line "all" is used, all days in the period are set for these times.

Time period: The start and stop time for the selected day for scheduling are selected here.

Adjusting: Whether or not cooling is permitted during scheduling is set here.

TIP

If you wish to set similar scheduling for every day of the week start by filling in "all" and then changing the desired days.

Caution

If the stop time is before the start time it means that the period extends past midnight.

Scheduling always starts on the date that the start time is set for.

Menu 1.3.3 - ventilation (accessory required)

Increases or decreases in the ventilation to the accommodation can be scheduled here for up to two time periods per day.

If two settings conflict with each other a red exclamation mark is displayed at the end of the line.

Schedule: The schedule to be changed is selected here.

Activated: Scheduling for the selected period is activated here. Set times are not affected at deactivation.

Day: Select which day or days of the week the schedule is to apply to here. To remove the scheduling for a particular day, the time for that day must be reset by setting the start time to the same as the stop time. If the line "all" is used, all days in the period are set for these times.

Time period: The start and stop time for the selected day for scheduling are selected here.

Adjusting: The desired fan speed is set here.

TIP

If you wish to set similar scheduling for every day of the week start by filling in "all" and then changing the desired days.

Caution

If the stop time is before the start time it means that the period extends past midnight.

Scheduling always starts on the date that the start time is set for.

Caution

A significant change over a longer period of time may cause poor indoor environment and worse operating economy.

Menu 1.9 - advanced

Menu advanced has orange text and is intended for the advanced user. This menu has several sub-menus.

heating curve Setting the heating curve slope.

external adjustment Setting the heat curve slope when the outer contact is connected. The menu is only displayed when the function is selected in menu 5.4.

min. flow line temp. Setting minimum permitted flow line temperature.

room sensor settings Settings regarding the room sensor.

cooling settings Settings for cooling.

fan return time Fan return time settings in the event of temporary ventilation speed change.

own curve Setting own heat curve.

point offset Setting the offset of the heating curve at a specific outdoor temperature.

Menu 1.9.1 - heating curve



heating curve

Setting range: 0 - 15

Default value: 9

In the menu heating curve the so-called heating curve for your house can be viewed. The task of the heating curve is to give an even indoor temperature, regardless of the outdoor temperature, and thereby energy efficient operation. It is from this heating curve that the heat pump's control computer determines the temperature of the water to the heating system, flow line temperature, and therefore the indoor temperature. You can select heating curve and read off how the flow line temperature changes at different outdoor temperatures here.

Curve coefficient



The slope of the heating curve indicates how many degrees the supply temperature is to be increased/reduced when the outdoor temperature drops/increases. A steeper slope means a higher supply temperature at a certain outdoor temperature.

The optimum slope depends on the climate conditions in your location, if the house has radiators or under floor heating and how well insulated the house is.

The heating curve is set when the heating installation is installed, but may need adjusting later. Thereafter the heating curve should not need further adjustment.

Caution

In the event of making fine adjustments for the indoor temperature, the heat curve must be offset up or down instead, this is done in menu 1.1 temperature.

Curve offset



An offset of the heating curve means that the supply temperature changes as much for all the outdoor temperatures, e.g. that a curve offset of +2 steps increases the supply temperature by 5 °C at all outdoor temperatures.

Flow line temperature– maximum and minimum values



Because the flow line temperature cannot be higher than the set maximum value or lower than the set minimum value the heating curve flattens out at these temperatures.

Caution

Underfloor heating systems are normally max flow line temperature set between 35 and 45 °C.

Check the max temperature for your floor with your floor supplier.

The figure at the end of the curve indicates the curve slope. The figure beside the thermometer gives the curve offset. Use the control knob to set a new value. Confirm the new setting by pressing the OK button.

Curve 0 is an own heating curve created in menu 1.9.7.

To select another heat curve (slope):

NOTE

If you only have one heating system, the number of the curve is already marked when the menu window opens.

1. Select the system (if more than one) for which the heat curve is to be changed.
2. When the system selection has been confirmed the heat curve number is marked.
3. Press the OK button to access the setting mode
4. Select a new heating curve. The heat curves are numbered from 0 to 15, the greater the number, the steeper the slope and the greater the supply temperature. Heating curve 0 means that own curve (menu 1.9.7) is used.
5. Press the OK button to exit the setting.

To read off a heating curve:

1. Turn the control knob so that the ring on the shaft with the outdoor temperature is marked.
2. Press the OK button.
3. Follow the grey line up to the heat curve and out to the left to read off the value for the supply temperature at the selected outdoor temperature.
4. You can now select to take read outs for different outdoor temperatures by turning the control knob to the right or left and read off the corresponding flow temperature.
5. Press the OK or Back button to exit read off mode.

TIP

Wait 24 hours before making a new setting, so that the room temperature has time to stabilise.

If it is cold outdoors and the room temperature is too low, increase the curve slope by one increment.

If it is cold outdoors and the room temperature is too high, lower the curve slope by one increment.

If it is warm outdoors and the room temperature is too low, increase the curve offset by one increment.

If it is warm outdoors and the room temperature is too high, lower the curve offset by one increment.

Menu 1.9.2 - external adjustment

climate system

Setting range: -10 to +10 or desired room temperature if the room sensor is installed.

Default value: 0

Connecting an external contact, for example, a room thermostat or a timer allows you to temporarily or periodically raise or lower the room temperature. When the contact is on, the heat curve offset is changed by the number of steps selected in the menu. If a room sensor is installed and activated the desired room temperature (°C) is set.

If there is more than one climate system the setting can be made separately for each system.

Menu 1.9.3 - min. flow line temp.

climate system

Setting range: 15 – 50 °C

Default value: 15 °C

Set the minimum temperature on the supply temperature to the climate system. This means that F1245 never calculates a temperature lower than that set here.

If there is more than one climate system the setting can be made separately for each system.

TIP

The value can be increased if you have, for example, a cellar that you always want to heat, even in summer.

Menu 1.9.4 - room sensor settings

factor system

Setting range: 0.2 - 3.0

Default value: 2.0

Room sensors to control the room temperature can be activated here.

Here you can set a factor that determines how much the supply temperature is to be affected by the difference between the desired room temperature and the actual room temperature. A higher value gives a greater change of the heat curve offset.

If several climate systems are installed the above settings can be made for the relevant systems.

Menu 1.9.5 - cooling settings (accessory required)

min. temp. cooling flow

Setting range: 5 - 50 °C

Default value: 10

cooling flow temp. at +20 °C

Setting range: 5 - 50 °C

Default value: 20

cooling flow temp. at +30 °C

Setting range: 5 - 50 °C

Default value: 15

time betw. switch heat/cool

Setting range: 0 - 48 h

Default value: 2

heat at room under temp.

Setting range: 0.5 - 10.0 °C

Default value: 1.0

cool at room over temp.

Setting range: 0.5 - 10.0 °C

Default value: 1.0

You can use F1245 to cool the house during hot periods.

Menu 1.9.6 - fan return time (accessory required)

speed 1-4

Setting range: 1 – 99 h

Default value: 4 h

Here you select the return time for temporary speed change (speed 1-4) on the ventilation in menu 1.2.

Return time is the time it takes before ventilation speed returns to normal.

Menu 1.9.7 - own curve

supply temperature

Setting range: 15 – 70 °C

You can create your own heating curve here, if there are special requirements, by setting the desired supply temperatures for different outdoor temperatures.

Caution

Curve 0 in menu 1.9.1 must be selected for this curve to apply.

Menu 1.9.8 - point offset

outdoor temp. point

Setting range: -40 – 30 °C

Default value: 0 °C

change in curve

Setting range: -10 – 10 °C

Default value: 0 °C

Select a change in the heating curve at a certain outdoor temperature here. A one degree change in room temperature requires one increment for underfloor heating and approximately two to three increments for the radiator system.

The heat curve is affected at ± 5 °C from set outdoor temp. point.

It is important that the correct heating curve is selected so that the room temperature is experienced as even.

TIP

If it is cold in the house, at, for example -2 °C, "outdoor temp. point" is set to "-2" and "change in curve" is increased until the desired room temperature is maintained.

Caution

Wait 24 hours before making a new setting, so that the room temperature has time to stabilise.

Menu 2 - HOT WATER

Overview

2 - HOT WATER	2.1 - temporary lux	
	2.2 - comfort mode	
	2.3 - scheduling	
	2.9 - advanced	2.9.1 - periodic increases

* Accessory needed.

Sub-menus

For the menu HOT WATER there are several sub-menus. Status information for the relevant menu can be found on the display to the right of the menus.

temporary lux Activation of temporary increase in the hot water temperature. Status information displays "off" or what length of time of the temporary temperature increase remains.

comfort mode Setting hot water comfort. The status information displays what mode is selected, "economy", "normal" or "luxury".

scheduling Scheduling hot water comfort. Status information "set" displays if any part of the schedule is active at present, "holiday setting" displays if vacation setting is in progress (menu 4.7), otherwise it displays "off".

advanced Setting periodic increase in the hot water temperature.

Menu 2.1 - temporary lux

Setting range: 3, 6 and 12 hours and mode "off"

Default value: "off"

When hot water requirement has temporarily increased this menu can be used to select an increase in the hot water temperature to lux mode for a selectable time.

Caution

If comfort mode "luxury" is selected in menu 2.2 no further increase can be carried out.

The function is activated immediately when a time period is selected and confirmed using the OK button. The time to the right displays the remaining time at the selected setting.

When the time has run out F1245 returns to the mode set in menu 2.2.

Select "off" to switch off temporary lux.

Menu 2.2 - comfort mode

Setting range: economy, normal, luxury

Default value: normal

The difference between the selectable modes is the temperature of the hot tap water. Higher temperature means that the hot water lasts longer.

economy: This mode gives less hot water than the other, but is more economical. This mode can be used in smaller households with a small hot water requirement.

normal: Normal mode gives a larger amount of hot water and is suitable for most households.

luxury: Lux mode gives the greatest possible amount of hot water. In this mode the immersion heater may be partially used to heat hot water, which may increase operating costs.

Menu 2.3 - scheduling

What hot water mode the heat pump is to work with can be scheduled here for up to two different time periods per day.

Scheduling is activated/deactivated by ticking/unticking "activated". Set times are not affected at deactivation.

If two settings conflict with each other a red exclamation mark is displayed.



Schedule: The schedule to be changed is selected here.

Activated: Scheduling for the selected period is activated here. Set times are not affected at deactivation.

Day: Select which day or days of the week the schedule is to apply to here. To remove the scheduling for a particular day, the time for that day must be reset by setting the start time to the same as the stop time. If the line "all" is used, all days in the period are set for these times.

Time period: The start and stop time for the selected day for scheduling are selected here.

Adjusting: Set the hot water mode that is to apply during scheduling here.

TIP

If you wish to set similar scheduling for every day of the week start by filling in "all" and then changing the desired days.

Caution

If the stop time is before the start time it means that the period extends past midnight.

Scheduling always starts on the date that the start time is set for.

Menu 2.9 - advanced

Menu advanced has orange text and is intended for the advanced user. This menu has several sub-menus.

Menu 2.9.1 - periodic increases

period

Setting range: 1 - 90 days

Default value: 14 days

start time

Setting range: 00:00 - 23:00

Default value: 02:00

To prevent bacterial growth in the heater, the compressor and the immersion heater can increase hot water temperature at regular intervals.

The length of time between increases can be selected here. The time can be set between 1 and 90 days. Factory setting is 14 days. Untick "activated" to switch off the function.

Menu 2.9.2 - hot water recirc. (accessory required)

operating time

Setting range: 1 - 60 min

Default value: 3 min

downtime

Setting range: 0 - 60 min

Default value: 12 min

Set the hot water circulation for up to three periods per day here. During the set periods the hot water circulation pump will run according to the settings above.

"operating time" decide how long the hot water circulation pump must run per operating instance.

"downtime" decide how long the hot water circulation pump must be stationary between operating instances.

Menu 3 - INFO

Overview

3 - INFO	3.1 - service info
	3.2 - compressor info
	3.3 - add. heat info
	3.4 - alarm log

Sub-menus

For the menu INFO there are several sub-menus. No settings can be made in these menus, it is just display of information. Status information for the relevant menu can be found on the display to the right of the menus.

service info shows temperature levels and settings in the heat pump.

compressor info shows operating times, number of starts etc for the compressor.

add. heat info displays information about the addition's operating times etc.

alarm log displays the latest alarm and information about the heat pump when the alarm occurred.

Menu 3.1 - service info

Information about the heat pump's actual operating status (e.g. current temperatures etc.) can be obtained here. No changes can be made.

The information is on several pages. Turn the control knob to scroll between the pages.

Symbols in this menu:

Compressor

Heating

Addition

Cooling

Brine pump (blue)

Pool

Heating medium pump (orange)

Ventilation

Hot water

Menu 3.2 - compressor info

Information about the compressor's operating status and statistics can be obtained here. No changes can be made.

The information is on several pages. Turn the control knob to scroll between the pages.

Menu 3.3 - add. heat info

Information about the additional heat settings, operating status and statistics can be obtained here. No changes can be made.

The information is on several pages. Turn the control knob to scroll between the pages.

Menu 3.4 - alarm log

To facilitate fault-finding the heat pump operating status at alarm alerts is stored here. You can see information for the 10 most recent alarms.

To view the run status in the event of an alarm, mark the alarm and press the OK button.

Menu 4 - HEAT PUMP

Overview

4 - HEAT PUMP	4.1 - plus functions *	4.1.1 - pool
	4.2 - op. mode	
	4.3 - my icons	
	4.4 - time & date	
	4.6 - language	
	4.7 - holiday setting	
	4.9 - advanced	4.9.1 - op. prioritisation
		4.9.2 - auto mode setting
		4.9.3 - degree minute setting
		4.9.4 - factory setting user
		4.9.4 - schedule blocking

* Accessory needed.

Sub-menus

For the menu HEAT PUMP there are several sub-menus. Status information for the relevant menu can be found on the display to the right of the menus.

plus functions Settings applying to any installed extra functions in the heating system.

op. mode Activation of manual or automatic operating mode. The status information shows the selected operating mode.

my icons Settings regarding which icons in the heat pump's user interface that are to appear in the slot when the door is closed.

time & date Setting current time and date.

language Select the language for the display here. The status information shows the selected language.

holiday setting Vacation scheduling heating, cooling and ventilation. Status information "set" is displayed if you set a vacation schedule but it is not active now, "active" displays if any part of the vacation schedule is active, otherwise it displays " off".

advanced Setting heat pump work mode.

Menu 4.1 - plus functions

Settings for any additional functions installed in the heating system can be made in the sub menus.

Menu 4.1.1 - pool (accessory required)

start temp

Setting range: 15.0 - 70.0 °C

Default value: 22.0 °C

stop temperature

Setting range: 15.0 - 70.0 °C

Default value: 24.0 °C

Select whether the pool control is to be activated and within what temperatures (start and stop temperature) pool heating must occur.

When the pool temperature drops below the set start temperature and there is no hot water or heating requirement, F1245 starts pool heating.

Untick "activated" to switch off the pool heating.

Caution

The start temperature cannot be set to a value that is higher than the stop temperature.

Menu 4.2 - op. mode

op. mode

Setting range: auto, manual, add. heat only

Default value: auto

functions

Setting range: compressor, addition, heating, cooling

The heat pump operating mode is usually set to "auto". It is also possible to set the heat pump to "add. heat only", but only when an addition is used, or "manual" and select yourself what functions are to be permitted.

Change the operating mode by marking the desired mode and pressing the OK button. When an operating mode is selected it shows what in the heat pump is permitted (crossed out = not permitted) and selectable alternatives to the right. To select selectable functions that are permitted or not you mark the function using the control knob and press the OK button.

Operating mode auto

In this operating mode you cannot select which functions are to be permitted or not because it is handled automatically by the heat pump.

Operating mode manual

In this operating mode you can select what functions are permitted or not. You cannot deselect "compressor" in manual mode.

Operating mode add. heat only

Caution

If you choose mode "add. heat only" the compressor is deselected and there is a higher operating cost.

In this operating mode the compressor is not active and only additional heat is used. You can also choose to deactivate heating or cooling (only if accessory for cooling is available or if the heat pump has an integrated cooling function).

Functions

"**compressor**" is that which produces heating and hot water for the accommodation. You cannot deselect "compressor" in manual mode. If "compressor" is deselected, a symbol in the main menu on the heat pump symbol is displayed.

"**addition**" is what helps the compressor to heat the accommodation and/or the hot water when it cannot manage the whole requirement alone.

"**heating**" means that you get heat in the accommodation. You can deselect the function when you do not wish to have heating running.

"**cooling**" means that you get cooling in the accommodation in hot weather. You can deselect the function when you do not wish to have the cooling running. This alternative requires an accessory for cooling or if the heat pump has a built in function for cooling.

Caution

If you deselect "addition" it may mean that sufficient cooling in the accommodation is not achieved.

Menu 4.3 - my icons

You can select what icon should be visible when the door to F1245 is closed. You can select up to 3 icons. If you select more, the ones you selected first will disappear. The icons are displayed in the order you selected them.

Menu 4.4 - time & date

Set time and date and display mode here.

Menu 4.6 - language

Choose the language that you want the information to be displayed in here.

Menu 4.7 - holiday setting

To reduce energy consumption during a holiday you can schedule a reduction in heating and hot water temperature. Cooling, ventilation and pool can also be scheduled if the functions are connected.

If a room sensor is installed and activated the desired room temperature (°C) is set during the time period. This setting applies to all climate systems with room sensors.

If a room sensor is not activated, the desired offset of the heat curve is set. This setting applies to all climate systems without room sensors. A one degree change in room temperature requires one increment for under floor heating and approximately two to three increments for the radiator system.

Vacation scheduling starts at 00:00 on the start date and stops at 23:59 on the stop date.

TIP

Complete holiday setting about a day before your return so that room temperature and hot water have time to regain usual levels.

TIP

Set the vacation setting in advance and activate just before departure in order to maintain the comfort.

Caution

If you choose to switch off hot water production during the vacation "periodic increases" (preventing bacterial growth) are blocked during this time. "periodic increases" started in conjunction with the vacation setting being completed.

Menu 4.9 - advanced

Menu advanced has orange text and is intended for the advanced user. This menu has several sub-menus.

Menu 4.9.1 - op. prioritisation

op. prioritisation

Setting range: 0 to 180

Default value: 20

Choose here how long the heat pump should work with each requirement if there are two or more requirements at the same time. If there is only one requirement the heat pump only works with that requirement.

The indicator marks where in the cycle the heat pump is.

If 0 minutes is selected it means that requirement is not prioritised, but will only be activated when there is no other requirement.

Menu 4.9.2 - auto mode setting

start cooling

Setting range: -20 – 40 °C

Default value: 25

stop heating

Setting range: -20 – 40 °C

Default value: 20

stop additional heat

Setting range: -20 – 40 °C

Default value: 15

filter time

Setting range: 0 – 48 h

Default value: 24 h

When operating mode is set to "auto" the heat pump selects when start and stop of additional heat and heat production is permitted, dependent on the average outdoor temperature. If you have accessories for cooling production installed you can also select start temperature for cooling.

Select the average outdoor temperatures in this menu.

You can also set the time over which (filter time) the average temperature is calculated. If you select 0, the present outdoor temperature is used.

Caution

"stop additional heat" cannot be set higher than "stop heating".

Caution

In systems where heating and cooling share the same pipes "stop heating" cannot be set higher than "start cooling".

Menu 4.9.3 - degree minute setting

current value

Setting range: -3000 – 3000

start compressor

Setting range: -1000 – -30

Default value: -60

start addition

Setting range: -2000 – -30

Default value: -400

diff. between additional steps

Setting range: 0 – 1000

Default value: 100

Degree minutes are a measurement of the current heating requirement in the house and determine when the compressor respectively additional heat will start/stop.

Caution

Higher value on "start compressor" gives more compressor starts, which increases wear in the compressor. Too low value can give uneven indoor temperatures.

Menu 4.9.4 - factory setting user

All settings that are available to the user (including advanced menus) can be reset to default values here.

Caution

After default setting, personal settings such as heat curves must be reset.

Menu 4.9.5 - schedule blocking

The compressor can be scheduled to be blocked for up to two different time periods here.

If two settings conflict with each other a red exclamation mark is displayed at the end of the line.

When scheduling is active the actual blocking symbol in the main menu on the heat pump symbol is displayed.



Schedule: The period to be changed is selected here.

Activated: Scheduling for the selected period is activated here. Set times are not affected at deactivation.

Day: Select which day or days of the week the schedule is to apply to here. To remove the scheduling for a particular day, the time for that day must be reset by setting the start time to the same as the stop time. If the line "all" is used, all days in the period are set for these times.

Time period: The start and stop time for the selected day for scheduling are selected here.

Blocking: The desired blocking is selected here.

Blocking the compressor.

Blocking additional heat.

TIP

If you wish to set similar scheduling for every day of the week start by filling in "all" and then changing the desired days.

Caution

If the stop time is before the start time it means that the period extends past midnight.

Scheduling always starts on the date that the start time is set for.

Caution

Long term blocking can cause reduced comfort and operating economy.

Menu 5 - SERVICE

Overview

5 - SERVICE	5.1 - operating settings	5.1.1 - hot water settings
		5.1.2 - max flow line temperature
		5.1.3 - max diff flow line temp.
		5.1.4 - alarm actions
		5.1.5 - fan sp. exhaust air *
		5.1.7 - br pmp al set.
		5.1.8 - operating mode brine pump
		5.1.9 - Brine pump speed
		5.1.10 - op. mod heat med pump
		5.1.11 - pump speed heating medium
		5.1.12 - internal electrical addition
	5.2 - system settings	
	5.3 - accessory settings	5.3.1 - FLM *
		5.3.2 - shunt controlled add. heat *
		5.3.3 - extra climate system *
	5.4 - soft in/outputs	
	5.5 - factory setting service	
	5.6 - forced control	
	5.7 - start guide	
	5.8 - quick start	

* Accessory needed.

Hold the Back button in for 7 seconds to access the Service menu.

Sub-menus

Menu SERVICE has orange text and is intended for the advanced user. This menu has several sub-menus. Status information for the relevant menu can be found on the display to the right of the menus.

operating settings Operating settings for the heat pump.

system settings System settings for the heat pump, activating accessories etc.

accessory settings Operational settings for different accessories.

soft in/outputs Setting software controlled in and outputs on the input circuit board (AA3).

factory setting service Total reset of all settings (including settings available to the user) to default values.

forced control Forced control of the different components in the heat pump.

start guide Manual start of the start guide which is run the first time the heat pump is started.

quick start Quick starting the compressor.

NOTE

Incorrect settings in the service menus can damage the heat pump.

Menu 5.1 - operating settings

Operating settings can be made for the heat pump in the sub menus.

Menu 5.1.1 - hot water settings

start temp.

Setting range: 5 – 70 °C

Factory setting economy: 38 °C

Factory setting normal: 45 °C

Factory setting luxury: 47 °C

stop temp.

Setting range: 5 – 70 °C

Factory setting economy: 43 °C

Factory setting normal: 50 °C

Factory setting luxury: 52 °C

stop temp. per. increase

Setting range: 55 – 70 °C

Default value: 55 °C

Here you set the start and stop temperature of the hot water for the different comfort options in menu 2.2 as well as the stop temperature for periodic increase in menu 2.9.1.

Menu 5.1.2 - max flow line temperature

climate system

Setting range: 15 – 80 °C

Default value: 60 °C

Set the maximum supply temperature for the climate system here. If the installation has more than one climate system, individual maximum supply temperatures can be set for each system.

Caution

Underfloor heating systems are normally max flow line temperature set between 35 and 45 °C.

Check the max temperature for your floor with your floor supplier.

Menu 5.1.3 - max diff flow line temp.

max diff compressor

Setting range: 1 – 25 °C

Default value: 10 °C

max diff addition

Setting range: 1 – 24 °C

Default value: 7 °C

Here you set the maximum permitted difference between the calculated and actual supply temperature during compressor respectively add. heat mode.

max diff compressor

When the current supply temperature **deviates** from the set value compared to that calculated, the heat pump is forced to stop irrespective of the degree-minute value.

If the calculated flow temperature **exceeds** the calculated flow with set value, the degree minute value is set to 0. The compressor stops when there is only a heating requirement.

max diff addition

If "addition" is selected and activated in menu 4.2 and the present supply temp **exceeds** the calculated with set value, the additional heat is forced to stop.

Menu 5.1.4 - alarm actions

Select how you want the heat pump to alert you that there is an alarm in the display here.

The different alternatives are that the heat pump stops producing hot water (default setting) and/or reduces the room temperature.

Menu 5.1.5 - fan sp. exhaust air (accessory is required)

normal and speed 1-4

Setting range: 0 – 100 %

Set the speed for the five different selectable speeds for the fan here.

Caution

Too low a value can damage the house in the long term.

Menu 5.1.7 - br pmp al set.

min. brine out

Setting range: -12 – 15 °C

Default value: -8 °C

max brine in

Setting range: 10 – 40 °C

Default value: 30 °C

min. brine out

Set the temperature at which the heat pump is to activate the alarm for low temperature in outgoing brine.

If "automatic reset" is selected, the alarm resets when the temperature has increased by 1 °C below the set value.

max brine in

Set the temperature at which the heat pump is to activate the alarm for high temperature in incoming brine.

Select "alarm activated" to activate the alarm.

Menu 5.1.8 - operating mode brine pump

op. mode

Setting range: intermittent, continuous, 10 days continuous

Default value: intermittent

Set the operating mode of the brine pump here.

intermittent: The brine pump starts 20 seconds before and stops at the same time as the compressor.

continuous: Continuous operation.

10 days continuous: Continuous operation for 10 days. Then the pump shifts to intermittent operation.

TIP

You can use "10 days continuous" at start-up to obtain continuous circulation during a start-up time in order to make it easier to bleed the system.

Menu 5.1.10 - op. mod heat med pump

op. mode

Setting range: auto, intermittent, continuous,

Default value: auto

Set the operating mode of the heating medium pump here.

auto: The heating medium pump runs according to the current operating mode for F1245.

intermittent: The heating medium pump starts 20 seconds before and stops at the same time as the compressor.

continuous: Continuous operation.

Menu 5.1.11 - pump speed heating medium

economy

Setting range: 0 - 100 %

Default values: 50 %

Set the speed at which the heat pump is to operate in the present operating mode.

"economy" means when the heating medium pump reduces in speed because the heat pump is in operating mode but neither has a need of compressor operation or electrical addition.

Menu 5.1.12 - internal electrical addition

max. electric power

Setting range: 0 - 9 kW

Default values: 3 kW

fuse size

Setting range: 1 - 200 A

Default values: 16 A

Set the max. electric power of the internal electrical addition in F1245 and the fuse size for the installation.

Menu 5.2 - system settings

Make different system settings for the heat pump here, e.g. which accessories are installed.

There are two ways of activating connected accessories. You can either mark the alternative in the list or use the automatic function "search installed acc.".

search installed acc.

Mark "search installed acc." and press the OK button to automatically find connected accessories for F1245.

Caution

"level sensor" are not found automatically but must be ticked off by hand.

Menu 5.3 - accessory settings

The operating settings for accessories that are installed and activated are made in the sub-menus for this.

Menu 5.3.1 - FLM

time between defrosts

Setting range: 1 – 30 h

Default value: 10 h

months btwn filter alarms

Setting range: 1 – 12

Default value: 3

continuous pump op.: Select for continuous operation of the circulation pump in NIBE FLM.

time between defrosts: Set the minimum time that must pass between defrostings of the heat exchanger in NIBE FLM.

When the exhaust air module is in operation the heat exchanger is cooled so that ice builds up on it. When too much ice builds up the heat transfer capacity of the heat exchanger is reduced and defrosting is required. Defrosting warms up the heat exchanger so that the ice melts and runs off via the condensation hose.

months btwn filter alarms: Set how many months should pass before the heat pump informs that it is time to clean the filter in NIBE FLM.

Clean NIBE FLM's two air filters regularly, how often depends on the amount of dust in the ventilation air.

Menu 5.3.2 - shunt controlled add. heat

minimum running time

Setting range: 0 – 48 h

Default value: 12 h

min temp.

Setting range: 5 – 90 °C

Default value: 55 °C

mixing valve amplifier

Setting range: 0.1 –10.0

Default value: 1.0

mixing valve step delay

Setting range: 10 – 300 s

Default values: 30 s

Set the minimum run time and the minimum temperature for external addition with shunt here. External addition with shunt is then for example wood/oil/gas/pellet boiler.

For the shunt you can set shunt amplification and shunt waiting time.

See the accessory installation instructions for function description.

Menu 5.3.3 - extra climate system

mixing valve amplifier

Setting range: 0.1 –10.0

Default value: 1.0

mixing valve step delay

Setting range: 10 – 300 s

Default values: 30 s

Set the shunt amplification and shunt waiting time for the different extra climate systems that are installed.

See the accessory installation instructions for function description.

Menu 5.4 - soft in/outputs

Here you can select which in/output on the input circuit board (AA3) the external contact function (page 23) is to be connected to.

Selectable inputs on terminal block AUX1-5 (AA3-X6:9-18) and output AA3-X7 (on the input circuit board).

Menu 5.5 - factory setting service

All settings can be reset (including settings available to the user) to default values here.

NOTE

When resetting, the start guide is displayed the next time the heat pump is restarted.

Menu 5.6 - forced control

You can force control the different components in the heat pump here.

Menu 5.7 - start guide

When the heat pump is started for the first time the start guide starts automatically. Start it manually here.

For more information about the different parts of the start guide, see page 27.

Menu 5.8 - quick start

It is possible to start the compressor from here.

Caution

There must be a heating demand to start the compressor.

Caution

Do not quick start the compressor too many times in succession over a short period of time as this may damage the compressor and its ancillary equipment.

Menu 5.10 - change log

Read off any previous changes to the control system here.

The date, time and ID no. (unique to certain settings) and the new set value is shown for every change.

NOTE

The change log is saved at restart and remains unchanged after default setting.

9 Service

Service actions

Emergency mode

NOTE

Switch (SF1) must not be moved to "I" or "⚠" until F1245 has been filled with water. Otherwise the temperature limiter, thermostat, compressor and the immersion heater can be damaged.

Emergency mode is used in event of operational interference and in conjunction with service. Hot water is not produced in emergency mode.

Emergency mode is activated by setting switch (SF1) to "⚠". This means that:

- The display is not lit and the control computer is not connected.
- The temperature at the immersion heater is controlled by the thermostat (FD1-BT30). It can be set either to 35 or 45 °C.
- The compressor and the brine system are off and only the heating medium pump and the electrical addition are active. The addition power in emergency mode is set in the immersion heater card (AA1). See page 22 for instructions.

Draining the water heater

The siphon principle is used to empty the hot water heater. This can be done either via the drain valve on the incoming cold water pipe or by inserting a hose into the cold water connection.





Draining the climate system

In order to carry out service on the climate system, it may be easier to drain the system first. This can be done in different ways depending on what needs doing:

NOTE

There may be some hot water when draining the heating medium side/climate system. There is a risk of scalding.

Draining the heating medium side in the cooling module

If, for example, the heating medium pump requires replacing or the cooling module requires servicing, drain the heating medium side as follows:

1. Close the shut-off valve for the heating medium side (QM32).
2. Connect a hose to the bleed valve (QM1) and open the valve. Some liquid will run out.

3. Air must get into the system for the remaining liquid to run out. Do this by slightly slackening off the connection at the shut-off valve (QM32) that joins the heat pump to the cooling module.

When the heating medium side is drained, the required service can be performed and/or replacement of any components carried out.

Draining the heating medium system in the heat pump

If the heat pump requires servicing, drain the heating medium side as follows:

1. Close the shut-off valves outside the heat pump for the heating medium side (return and flow line).
2. Connect a hose to the bleed valve (QM1) and open the valve. Some liquid will run out.
3. Air must get into the system for the remaining liquid to run out. Do this by slightly slackening off the connection at the shut-off valve that joins the climate system and the heat pump at the connection (XL2).

When the heating medium side is empty the requisite service can be carried out.

Draining the entire climate system

If the entire climate system requires draining, do this as follows:

1. Connect a hose to the bleed valve (QM1) and open the valve. Some liquid will run out.
2. Air must get into the system for the remaining liquid to run out. This is done by unscrewing the bleed screw on the highest radiator in the house.

When the climate system is empty the requisite service can be carried out.

Emptying the brine system

In order to service the brine system it may be easier to drain the system first. This can be done in different ways depending on what needs doing:

Draining the brine system in the cooling module

If, for example, the brine pump requires replacing or the cooling module requires servicing, drain the brine system by:

1. Close the shut-off valves to brine system (QM33) and (QM34).
2. Connect a hose to the drain valve (QM2), place the other opening of the hose in a container and open the valve. A small amount of brine will flow into the container.
3. Air must get into the system for the remaining brine to run out. Do this by slightly slackening off the connection at the shut-off valve (QM33) that joins the heat pump with the cooling module.

When the brine side is empty the requisite service can be carried out.

Draining the brine system in the heat pump

If the heat pump requires servicing, drain the brine system by:

1. Close the shut-off valve outside the heat pump for the brine system.
2. Connect a hose to the drain valve (QM2), place the other opening of the hose in a container and open the valve. A small amount of brine will flow into the container.
3. Air must get into the system for the remaining brine to run out. Do this by slightly slackening off the connection at the shut-off valve that joins the brine side and the heat pump at the connection (XL7).

When the brine side is empty the requisite service can be carried out.

Helping the circulation pump to start (GP1)

NOTE

Help starting the heating medium pump (GP1) only applies to F1245 -5 to -12 kW.

1. Shut off F1245 by setting the switch (SF1) to " ⏻".
2. Open the service cover.
3. Remove the cover for the cooling module.
4. Loosen the venting screw (QM5) with a screwdriver. Hold a cloth around the screwdriver blade as a small amount of water may run out.
5. Insert a screwdriver and turn the pump motor around.
6. Screw in the venting screw (QM5).
7. Start F1245 and check that the circulation pump functions.

It is usually easier to start the circulation pump with F1245 running, switch (SF1) set to " I". Helping the circulation pump to start is performed with F1245 running, be prepared for the screwdriver to jerk when the pump starts.



Temperature sensor data

Temperature (°C)	Resistance (k Ω)	Voltage (VDC)
-40	351.0	3.256
-35	251.6	3.240
-30	182.5	3.218
-25	133.8	3.189
-20	99.22	3.150
-15	74.32	3.105
-10	56.20	3.047
-5	42.89	2.976
0	33.02	2.889
5	25.61	2.789
10	20.02	2.673
15	15.77	2.541
20	12.51	2.399
25	10	2.245
30	8.045	2.083
35	6.514	1.916
40	5.306	1.752
45	4.348	1.587
50	3.583	1.426
55	2.968	1.278
60	2.467	1.136
65	2.068	1.007
70	1.739	0.891
75	1.469	0.785
80	1.246	0.691
85	1.061	0.607
90	0.908	0.533
95	0.779	0.469
100	0.672	0.414

Pulling out the cooling module

The cooling module can be pulled out for service and transport.

Caution

The cooling module is easier to remove if it is drained first (see page 63).

Weight of the cooling module

Type (kW)	Weight (kg)
5	110
6	115
8	125
10	130
12	135

NOTE

Shut off the heat pump and turn off the current on the safety breaker.

Caution

Remove the front cover according to the description on page 7.

1 Close the shut-off valves (QM32), (QM33) and (QM34).



2 Pull off the lock catches.



3 Disconnect the pipe connection at the pipe coupling (WP4).

4 Remove the two screws.



5 Remove the connections from the base card (AA2) using a screwdriver.



6 Disconnect the connectors (A) and (B) from the underside of the base card cabinet.

7 Disconnect the connector (C) from the immersion heater circuit board (AA1) using a screwdriver.

8 Disconnect the connector (D) from the joint circuit board (AA100).

9 Carefully pull out the cooling module.



TIP

The cooling module is installed in reverse order.

USB service outlet



F1245 is equipped with a USB socket in the display unit. This USB socket can be used to connect a USB memory to update the software, save logged information and handle the settings in F1245.



When a USB memory is connected a new menu (menu 7) appears in the display.

Menu 7.1 - update firmware



This allows you to update the software in F1245.

NOTE

For the following functions to work the USB memory must contain files with software for F1245 from NIBE.

The fact box at the top of the display shows information (always in English) of the most probable update that the update software has selected form the USB memory.

This information states which product the software is intended for, the software version and general information about them. If you wish to select another file than the one selected, the correct file can be selected by "choose another file".

start updating

Select "start updating" if you want to start the update. You are asked whether you really want to update the software. Respond "yes" to continue or "no" to undo.

If you responded"yes" to the previous question the update starts and you can follow the progress of the update on the display. When the update is complete F1245 restarts.

NOTE

A software update does not reset the menu settings in F1245.

NOTE

If the update is interrupted before it is complete (for example power cut etc.) the software can be reset to the previous version if the OK button is held in during start up.

choose another file



Select "choose another file" if you do not want to use the suggested software. When you scroll through the files, information about the marked software is shown in a fact box just as before. When you have selected a file with the OK button you will return to the previous page (menu 7.1) where you can choose to start the update.

Menu 7.2 - logging



Setting range: 1 s – 60 min

Default setting range: 5 s

Set whether the present measurement values from F1245 are to be saved in a log on the USB memory.

Read the present measurement values

1. Mark "read log settings" and press the OK button.
2. The present values from F1245 are saved in a file on the USB memory.

Log for longer periods

1. Set the desired interval between loggings.
2. Tick "activated".
3. Mark "read log settings" and press the OK button.
4. The present values from F1245 are saved in a file in the USB memory at the set interval until "activated" is unticked.

Menu 7.3 - manage settings



Here you can manage (save as or retrieve from) all the menu settings (user and service menus) in F1245 with a USB memory.

Via "save settings" you save the menu settings to the USB memory in order to restore them later.

NOTE

When you save the menu settings to the USB memory you replace all previously saved settings.

Via "recover settings" you reset all menu settings from the USB memory.

NOTE

Reset of the menu settings from the USB memory cannot be undone.

10 Disturbances in comfort

In most cases, the heat pump notes operational interference (operational interference can lead to disturbance in comfort) and indicates this with alarms and shows action instructions in the display.

Info-menu

All the heat pump measurement values are gathered under menu 3.1 in the heat pump menu system. Looking through the values in this menu can often simplify finding the fault source. See page 53 for more information about menu 3.1.

Manage alarm

In the event of an alarm, some kind of malfunction has occurred, which is indicated by the status lamp changing from green continuously to red continuously. In addition, an alarm bell appears in the information window.

Alarm

In the event of an alarm with a red status lamp a malfunction has occurred that the heat pump cannot remedy itself. In the display, by turning the control knob and pressing the OK button, you can see the type of alarm it is and reset it. You can also choose to set the heat pump to aid mode.

info / action Here you can read what the alarm means and receive tips on what you can do to correct the problem that caused the alarm.

reset alarm In most cases it is enough to select "reset alarm" to correct the problem that caused the alarm. If a green light illuminates after selecting "reset alarm" the alarm has been remedied. If a red light is still visible and a menu called "alarm" is visible in the display, the problem that caused the alarm remains. If the alarm disappears and then returns, contact your installer.

aid mode "aid mode" is a type of emergency mode. This means that the heat pump produces heat and/or hot water despite there being some kind of problem. This can mean that the heat pump's compressor is not running. In this case the immersion heater produces heat and/or hot water.

Selecting "aid mode" is not the same as correcting the problem that caused the alarm. The status lamp will therefore continue to be red.

Troubleshooting

If the operational interference is not shown in the display the following tips can be used:

Basic actions

Start by checking the following possible fault sources:

- The switch's (SF1) position.
- Group and main fuses of the accommodation.
- The property's earth circuit breaker.
- The heat pump's miniature circuit breaker (FA1).
- The heat pump's temperature limiter (FD1).
- Correctly set load monitor (if installed).

Low hot water temperature or a lack of hot water

- Heat pump in incorrect operating mode.
  - If mode "manual" is selected, select "addition".
- Large hot water consumption.
  - Wait until the hot water has heated up. Temporarily increased hot water capacity (temporary lux) can be activated in menu 2.1.
- Too low hot water setting.
  - Enter menu 2.2 and select a higher comfort mode.
- Too low or no operating prioritisation of hot water.
  - Enter menu 4.9.1 and increase the time for when hot water is to be prioritised.
- Closed or choked filling valve (QM10) for the hot water heater.
  - Open the valve.

Low room temperature

- Closed thermostats in several rooms.
  - Set the thermostats to max in as many rooms as possible. Adjust the room temperature via menu 1.1 instead of choking the thermostats.
- Heat pump in incorrect operating mode.
  - Enter menu 4.2. If mode "auto" is selected, select a higher value on "stop heating" in menu 4.9.2.
  - If mode "manual" is selected, select "heating". If this is not enough, select "addition".
- Too low set value on the automatic heating control.
  - Enter menu 1.1 (temperature) and adjust the heat curve offset of the heat curve. If the room temperature is only low in cold weather the curve slope in the menu 1.9.1 (heating curve) needs to be adjusted up.

- Too low or no operating prioritisation of heat.
  - Enter menu 4.9.1 and increase the time for when heating is to be prioritised.
- Holiday mode activated in menu 1.3.4.
  - Enter menu 1.3.4 and select "Off".
- External switch for changing the room heating activated.
  - Check any external switches.
- Circulation pump(s) (GP1 and/or GP2) stopped.
  - See section "Helping the circulation pump to start" on page 64.
- Air in the climate system.
  - Vent the climate system (see page 26).
- Closed valves (QM20), (QM32) to the climate system.
  - Open the valves.

High room temperature

- Too high set value on the automatic heating control.
  - Enter menu 1.1 (temperature) and adjust the heat curve offset downwards. If the room temperature is only high in cold weather the curve slope in menu 1.9.1 (heating curve) needs to be adjusted down.
- External switch for changing the room heating activated.
  - Check any external switches.

Low system pressure

- Not enough water in the climate system.
  - Top up the water in the climate system (see page 26).

Low or a lack of ventilation

This part of the fault-tracing chapter only applies if the NIBE FLM accessory is installed.

- Filter (HQ10) blocked.
  - Clean or replace filter.
- Exhaust air device blocked or throttled down too much.
  - Check and clean the exhaust air devices.
- Fan speed in reduced mode.
  - Enter menu 1.2 and select "normal".
- External switch for changing the fan speed activated.
  - Check any external switches.

High or distracting ventilation

This part of the fault-tracing chapter only applies if the NIBE FLM accessory is installed.

- The ventilation is not adjusted.
  - Order/implement ventilation adjustment.
- Fan speed in forced mode.
  - Enter menu 1.2 and select "normal".
- External switch for changing the fan speed activated.
  - Check any external switches.
- Filter (HQ10) blocked.
  - Clean or replace the filter.

The compressor does not start

- There is no heating requirement.
  - The heat pump does not call on heating nor hot water.
- Minimum time between compressor starts has not been reached.
  - Wait 30 minutes and check if the compressor has started.
- Alarm tripped.
  - Follow the display instructions.

Gurgling sound

This part of the fault-tracing chapter only applies if the NIBE FLM accessory is installed.

- Not enough water in the water seal.
  - Fill the water seal with water.
- Choked water seal.
  - Check and adjust the condensation water hose.

11 Accessories

Load monitor CLM 40

Part no. 067 070

ELK

ELK 213

Part no. 069 500

ELK 5/8/15

ELK 5 Part no. 069 025

ELK 8 Part no. 069 026

ELK 15 Part no. 069 022

ELK 26

Part no. 067 074

ELK 42

Part no. 067 075

Extra shunt group ECS 40

This accessory is used when F1245 is installed in houses with two or more different climate systems that require different supply temperatures, for example, in cases where the house has both a radiator system and an underfloor heating system.

Part no. 067 061

Free cooling PCS 44

Part no. 067 063

Exhaust air module FLM

FLM is an exhaust air module specially designed to combine recovery of mechanical exhaust air with an energy collector in rock.

FLM

Part no. 067 011

Bracket pack FLM

Part no. 037 399

Auxiliary relay HR 10

Part no. 089 423

Level monitor NV 10

Part no. 089 315

Pool heating POOL 40

POOL 40 is an accessory that enables pool heating with F1245.

Part no. 067 062

Filling valve kit KB R25/G32

Filling valve kit for filling brine in the collector hose for rock heat pumps. Includes dirt filter and insulation.

KB R25 (max 12 kW)

Part no. 089 368

KB G32 (max 30 kW)

Part no. 089 368

Accessory card AXC 40

An accessory card is required if the ground water pump, cooling mode indication* or hot water circulation pump** is connected to F1245 at the same time that the buzzer alarm is activated (see page 71).

Kit for accessories card is included in most accessories that require it.

* Only applies if accessories for cooling are present or if the heat pump has the integrated cooling function.

** Only applies to enamelled or stainless steel vessels.

Part no. 067 060

12 Technical data

Dimensions and setting-out coordinates



*Because the angle of the brine pump pipes consists of a flex hose, the pipes can be adjusted several cm in height at the side connection.

Technical specifications

CE IP 21

1x230V

1x230V		5	8	12
Output data at nom flow Refers to performance of heat pump excl. circulation pumps				
0/35				
Rated output	kW	4.83	8.33	11.88
Cooling output	kW	3.74	6.60	9.30
Electrical output	kW	1.09	1.73	2.58
COP	-	4.44	4.82	4.60
0/50				
Rated output	kW	3.85	7.80	11.25
Cooling output	kW	2.62	5.54	7.90
Electrical output	kW	1.23	2.26	3.35
COP	-	3.13	3.45	3.36
Output data according to EN 14511				
0/35				
Rated output	kW	4.65	8.15	11.60
Electrical output	kW	1.13	1.84	2.72
$COP_{EN14511}$	-	4.12	4.44	4.27
0/45				
Rated output	kW	3.98	7.75	10.99
Electrical output	kW	1.21	2.18	3.20
$COP_{EN14511}$	-	3.29	3.55	3.44
Additional power	kW	2/4/6/7		
Electrical data				
Rated voltage		230V 50 Hz		
Max operating current, compressor (Including Control system and Circulation pumps)	A_{rms}	9.5	15	22.5
Starting current	A_{rms}	23	32	40
Max permitted impedance at connection point [1)]	ohm	-	-	-
Max operating current heat pump including 2 kW immersion heater (Recommended fuse rating)	A_{rms}	18(20)	24(25)	31(32)
Max operating current heat pump including 4 kW immersion heater (Recommended fuse rating)	A_{rms}	27(32)	32(32)	40(40)
Max operating current heat pump including 6 kW immersion heater (Recommended fuse rating)	A_{rms}	36(40)	41(50)	49(50)
Max operating current heat pump including 7 kW immersion heater (Recommended fuse rating)	A_{rms}	40(40)	46(50)	53(63)
Output, Brine pump	W	30 – 87	30 – 87	35 – 185
Output, Heating medium pump	W	7 – 72	7 – 72	7 – 72
IP class		IP 21		
Refrigerant circuit				
Type of refrigerant		R407C		
Volume	kg	1.4	2.3	2.2
Cut-out value pressostat HP	(bar)	29		
Difference pressostat HP	(bar)	-7		
Cut-out value pressostat LP	(bar)	1.5		
Difference pressostat LP	(bar)	1.5		

1x230V		5	8	12
Brine circuit				
Energy class Brine pump		low energy		
Max system pressure brine	(bar)	3		
Min flow	l/s	0.19	0.33	0.47
Nominal flow	l/s	0.23	0.42	0.65
Max external avail. press at nom flow	kPa	54	46	69
Max/Min incoming Brine temp	°C	see diagram		
Min. outgoing brine temp.	°C	-10		
Heating medium circuit				
Energy class circ-pump		low energy		
Max system pressure heating medium	(bar)	3		
Min flow	l/s	0.08	0.13	0.19
Nominal flow	l/s	0.10	0.18	0.27
Max external avail. press at nom flow	kPa	52	48	43
Max/Min heating medium temp	°C	see diagram		
Noise output according to EN 12102 at 0/35	Lw(A)	43	43	43
Pipe connections				
Brine ext diam. CU pipe	mm	28		
Heating medium ext diam. CU pipes	mm	22		28
Hot water connection external diam	mm	22		
Cold water connection external diam	mm	22		

3x230V

Will be launched at a later date.

3x400V

3x400V		6	8	10	12
Output data at nom flow Refers to performance of heat pump excl. circulation pumps					
0/35					
Rated output	kW	6.31	8.30	9.95	11.82
Cooling output	kW	5.03	6.64	7.97	9.35
Electrical output	kW	1.28	1.66	1.98	2.47
COP	-	4.93	5.01	5.03	4.79
0/50					
Rated output	kW	5.10	6.94	8.46	11.15
Cooling output	kW	3.63	4.98	6.08	7.86
Electrical output	kW	1.48	1.96	2.38	3.29
COP	-	3.46	3.54	3.39	3.39
Output data according to EN 14511					
0/35					
Rated output	kW	6.10	8.01	9.64	11.42
Electrical output	kW	1.35	1.74	2.13	2.66
$COP_{EN14511}$	-	4.51	4.59	4.52	4.30
0/45					
Rated output	kW	5.21	7.07	8.55	10.86
Electrical output	kW	1.46	1.93	2.36	3.20
$COP_{EN14511}$	-	3.58	3.66	3.63	3.39
Additional power	kW	2/4/6/9			
Electrical data					
Rated voltage		400V 3NAC 50 Hz			

3x400V		6	8	10	12
Max operating current, compressor (Including Control system and Circulation pumps)	A_{rms}	4.6	6.6	6.9	9
Starting current	A_{rms}	18	23	23	29
Max permitted impedance at connection point [1)]	ohm	-	-	-	-
Max operating current heat pump including 2 kW immersion heater (Recommended fuse rating)	A_{rms}	13(16)	15(16)	15(16)	18(20)
Max operating current heat pump including 4 kW immersion heater (Recommended fuse rating)	A_{rms}	13(16)	15(16)	15(16)	18(20)
Max operating current heat pump including 6 kW immersion heater (Recommended fuse rating)	A_{rms}	13(16)	15(16)	15(16)	18(20)
Max operating current heat pump including 9 kW immersion heater (Recommended fuse rating)	A_{rms}	19(20)	22(25)	22(25)	24(25)
Output, Brine pump	W	30 – 87	30 – 87	35 – 185	35 – 185
Output, Heating medium pump	W	7 – 72	7 – 72	7 – 72	7 – 72
IP class		IP 21			
Refrigerant circuit					
Type of refrigerant		R407C			
Volume	kg	1.8	2.3	2.5	2.2
Cut-out value pressostat HP	(bar)	29			
Difference pressostat HP	(bar)	-7			
Cut-out value pressostat LP	(bar)	1.5			
Difference pressostat LP	(bar)	1.5			
Brine circuit					
Energy class Brine pump		low energy			
Max system pressure brine	(bar)	3			
Min flow	l/s	0.25	0.33	0.40	0.47
Nominal flow	l/s	0.30	0.42	0.51	0.65
Max external avail. press at nom flow	kPa	53	46	85	69
Max/Min incoming Brine temp	°C	see diagram			
Min. outgoing brine temp.	°C	-10			
Heating medium circuit					
Energy class circ-pump		low energy			
Max system pressure heating medium	(bar)	3			
Min flow	l/s	0.10	0.13	0.63	0.19
Nominal flow	l/s	0.13	0.18	0.22	0.27
Max external avail. press at nom flow	kPa	46	48	46	43
Max/Min heating medium temp	°C	see diagram			
Noise output according to EN 12102 at 0/35	Lw(A)	43	43	43	43
Pipe connections					
Brine ext diam. CU pipe	mm	28			
Heating medium ext diam. CU pipes	mm	22			28
Hot water connection external diam	mm	22			
Cold water connection external diam	mm	22			

Miscellaneous

Miscellaneous		5	6	8	10	12
Water heater						
Volume water heater	l	180				

Miscellaneous		5	6	8	10	12
Max pressure in water heater	(bar)			9		
Dimensions and weight						
Width	mm			600		
Depth	mm			620		
Height	mm			1800		
Required ceiling height [2)]	mm			1950		
Weight complete heat pump	kg	305	310	325	330	335
Weight only cooling module	kg	110	115	125	130	135
Part no. 1x230V, Stainless steel		665 361	-	665 363	-	665 365
Part no., 3x400V, Enamel		-	665 302	665 303	665 304	665 305
Part no. 3x400V, Stainless steel		-	665 322	665 323	665 324	665 325
Part no. 3x400V, Copper		-	665 282	665 283	665 284	665 285

[1)]Max. permitted impedance in the mains connected point in accordance with EN 61000-3-11. Start currents can cause short voltage dips that could affect other equipment in unfavourable conditions. If the impedance in the mains connection point is higher than that stated it is possible that interference will occur. If the impedance in the mains connection point is higher than that stated check with the power supplier before purchasing the equipment.

[2)]With feet dismantled the height is approx. 1930 mm.

Working range heat pump, compressor operation

The compressor provides a supply temperature up to 65 °C, the remainder (up to 70 °C) is obtained using the additional heat.

12 kW 3x400V, 8-12 kW 1x230V



Others



13 Item register

Item register

A
Accessibility, electrical connection, 19
Accessories, 71
Assembly, 5

B
Back button, 39
Blocking of additional heat and/or compressor, 24
Brine side, 14

C
Cable lock, 18
Commissioning and adjusting, 26
  Filling and venting, 26
  Post adjustment and bleeding, 36
  Preparations, 26
  Start guide, 27
Connecting accessories, 25
Connecting current sensors, 23
Connecting external operating voltage for the control system, 20
Connecting the climate system, 15
Connecting the hot water heater, 15
Connections, 20
Contact for activation of fan speed, 24
Contact for activation of "external adjustment", 24
Contact for activation of "temporary lux", 24
Contact information, 4
Control, 39, 43
  Control - Introduction, 39
  Control - Menus, 43
Control - Introduction, 39
  Display unit, 39
  Menu system, 40
Control knob, 39
Controlling ground water pump, 25
Control - Menus, 43
  Menu 1 - INDOOR CLIMATE, 43
  Menu 2 - HOT WATER, 51
  Menu 3 - INFO, 53
  Menu 4 - HEAT PUMP, 54
  Menu 5 - SERVICE, 58
Cooling mode indication, 25
Cooling section, 12

D
Delivery and handling, 5
  Assembly, 5
  Drawing out the cooling module, 5
  Installation area, 6
  Removing parts of the insulation, 7
  Removing the covers, 7
  Supplied components, 6
  Transport, 5
Dimensions and pipe connections, 14
Dimensions and setting-out coordinates, 72
Display, 39
Display unit, 39
  Back button, 39
  Control knob, 39
  Display, 39
  OK button, 39
  Status lamp, 39
  Switch, 39
Disturbances in comfort, 69
  Manage alarm, 69
  Troubleshooting, 69
Docking alternatives, 16
  Extra electric hot water heater, 16
  Free cooling, 16
  Ground water system, 17
  Neutralization vessel, 16
  Pool, 17
  Two or more climate systems, 17
  Under floor heating systems, 17
  Ventilation recovery, 16
Draining the climate system, 63
Draining the water heater , 63
Drawing out the cooling module, 5, 65

E
Electrical addition - maximum output, 22
  Setting of electrical steps, 22
Electrical cabinets, 10
Electrical connections, 18
  Accessibility, electrical connection, 19
  Cable lock, 18
  Connecting accessories, 25
  Connecting external operating voltage for the control system, 20
  Connections, 20
  Electrical addition - maximum output, 22
  External connection options, 24
  General, 18
  Load monitor, 23
  Miniature circuit-breaker, 18
  Motor cut-out, 18
  Optional connections, 23
  Outdoor sensor, 21
  Power connection, 20
  Removing the cover, base board, 19
  Removing the cover, immersion heater circuit board, 19
  Removing the hatch, input circuit board, 19
  Room sensor, 21
  Settings, 22
  Standby mode, 22
  Temperature limiter, 18
Emptying the brine system, 64
External connection options, 24
  Blocking of additional heat and/or compressor, 24
  Contact for activation of fan speed, 24
  Contact for activation of "external adjustment", 24
  Contact for activation of "temporary lux", 24
  Controlling ground water pump, 25
  Cooling mode indication, 25
  Hot water circulation, 25
  Indication of buzzer alarms, 25
  NV 10, pressure/level/flow monitor brine, 24

F
Filling and venting, 26
  Filling and venting the brine system, 26
  Filling and venting the climate system, 26
  Filling the hot water heater, 26
  Symbol key, 27
Filling and venting the brine system, 26
Filling and venting the climate system, 26
Filling the hot water heater, 26

H
Heating medium side, 15
  Connecting the climate system, 15
Helping the circulation pump to start, 64
Help menu, 42
Hot water circulation, 25
Hot water heater, 15
  Connecting the hot water heater, 15

I
Important information, 2
Safety information, 2
Indication of buzzer alarms, 25
Inspection of the installation, 3
Installation area, 6

M
Manage alarm, 69
Menu 1 - INDOOR CLIMATE, 43
Menu 2 - HOT WATER, 51
Menu 3 - INFO, 53
Menu 4 - HEAT PUMP, 54
Menu 5 - SERVICE, 58
Menu system, 40
Help menu, 42
Operation, 41
Scroll through the windows, 42
Selecting menu, 41
Selecting options, 41
Setting a value, 42
Miniature circuit-breaker, 18
Motor cut-out, 18
Resetting, 18

N
NV 10, pressure/level/flow monitor brine, 24

O
OK button, 39
Operation, 41
Optional connections, 23
Outdoor sensor, 21

P
Pipe connections, 13
Brine side, 14
Dimensions and pipe connections, 14
Docking alternatives, 16
General, 13
Heating medium side, 15
Hot water heater, 15
Pipe dimensions, 14
Symbol key, 13
System diagram, 13
Pipe dimensions, 14
Post adjusting the room temperature, 38
Post adjustment and bleeding, 36
Post adjusting the room temperature, 38
Pump capacity diagrams, collector side, 36
Pump capacity diagrams, heating medium side, 37
Readjusting, venting, heat medium side, 38
Power connection, 20
Preparations, 26
Pump capacity diagrams, collector side, 36
Pump capacity diagrams, heating medium side, 37

R
Readjusting, venting, heat medium side, 38
Removing parts of the insulation, 7
Removing the cover, base board, 19
Removing the cover, immersion heater circuit board, 19
Removing the covers, 7
Removing the hatch, input circuit board, 19
Room sensor, 21

S
Safety information, 2
Contact information, 4
Inspection of the installation, 3
Serial number, 2
Symbols, 2
Scroll through the windows, 42
Selecting menu, 41
Selecting options, 41
Serial number, 2
Service, 63
Service actions, 63
Service actions, 63
Draining the climate system, 63
Draining the water heater , 63
Drawing out the cooling module, 65
Emptying the brine system, 64
Helping the circulation pump to start, 64
Standby mode, 63
Temperature sensor data, 65
USB service outlet, 67
Setting a value, 42
Settings, 22
Standby mode, 63
Power in emergency mode, 22
Start guide, 27
Start-up and inspection
Start-up , 27
Status lamp, 39
Supplied components, 6
Switch, 39
Symbol key, 13, 27
Symbols, 2
System diagram, 13

T
Technical data, 72
Dimensions and setting-out coordinates, 72
Technical Data, 73
Technical Data, 73
Working range heat pump, 76
Temperature limiter, 18
Resetting, 18
Temperature sensor data, 65
The heat pump design, 9
Component list cooling section, 12
Component list electrical cabinets, 10
Component location cooling section, 12
Component location electrical cabinets, 10
Component locations, 9
List of components, 9
Transport, 5
Troubleshooting, 69

U
USB service outlet, 67

W
Working range heat pump, 76

NIBE AB Sweden
Järnvägsgatan 40
Box 14
SE-285 21 Markaryd
info@nibe.se
www.nibe.eu

031337